D D 111 1	D	1 - 0	M 1110 21N 1 D
Rev Part Number A MC153-00200	<u>Replaces</u> 153-00200, 762-534	<u>Location</u> Main	Model and Serial Number Range J-3 s/n all (When equipped with wheel 40-60);
A	100 00200, 102-004	Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
		1110111	wheel 40-60);
A		Main	J3C-40 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50S s/n all (When equipped with wheel 40-60);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
		WIGHT	(When equipped with wheel 40-60);
A		Main	J3C-65S s/n all (When equipped with wheel 40-60);
A		Main	J3F-50 s/n all (When equipped with wheel 40-60);
A		Main	J3F-50S s/n all (When equipped with wheel 40-60);
A		Main	J3F-60 s/n all (When equipped with wheel 40-60);
A			
A		Main	J3F-60S s/n all (When equipped with wheel 40-60);
		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-60);
A		Main	J3F-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L s/n all (When equipped with wheel 40-60);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel
1			40-60);
A		Main	J3L-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L-S s/n all (When equipped with wheel 40-60);
A		Main	J3P s/n all (When equipped with wheel 40-60);
A		Main	J4 s/n all (When equipped with wheel 40-60);
A		Main	J4A s/n all (When equipped with wheel 40-60);
A		Main	J4A-S s/n all (When equipped with wheel 40-60);
A		Main	J4B s/n all (When equipped with wheel 40-60);
A		Main	J4E (Army L-4E) s/n all (When equipped with wheel
			40-60):
A		Main	J4F s/n all (When equipped with wheel 40-60);
A		Main	AE-1 s/n all (When equipped with wheel 40-60);
A		Main	HE-1 s/n all (When equipped with wheel 40-60);
A		Main	J5A (Army L-4F) s/n all (When equipped with wheel
		Wall	40-60);
A		Main	J5A-80 s/n all (When equipped with wheel 40-60);
A		Main	
		IVIAIII	J5B (Army L-4G) s/n all (When equipped with wheel
A		Main	40-60);
A		Main	J5C s/n all (When equipped with wheel 40-60); PA-11 s/n all (When equipped with wheel 40-60);
A			, , , , , ,
		Main	PA-11S s/n all (When equipped with wheel 40-60);
A		Main	PA-12 s/n all (When equipped with wheel 40-60);
		Main	PA-12S s/n all (When equipped with wheel 40-60);
		Main	PA-14 s/n all (When equipped with wheel 40-60);
		Main	PA-15 s/n all (When equipped with wheel 40-60);
_ ^		Main	PA-16 s/n all (When equipped with wheel 40-60);
_ ^		Main	PA-16S s/n all (When equipped with wheel 40-60);
A		Main	PA-17 s/n all (When equipped with wheel 40-60);
			Project Engineer: O / O F Qualify the page of O
			Printe P. Hartne 15, P.E.
			John: 12/01/2020 Date: 10 0000
			Engineering Manager: Manufacturing Manager: One of Michaele
			100 les per 12/9/2020 Date: 12-9-2020
			M.F. day a dalla S
			MCFarlane 696 East 1700 Road
			Baldwin City, Kansas 66006
			Tide:
			ELIGIBILITY: WHEEL SEAL KIT PIPER
			Size: A Scale: NA Drawn: LLE Sheet: 1 of 79
В 12/09/2020	SEE REVISION S	SHEET	Drawling Number: REVISION
A 10/20/2017	SEE REVISION S		В В
~ 03/24/2011	ORIGINAL		

A MC153-	00200 153-00200, 762-534	Main Main	PA-18 s/n all (When equipped with wheel 40-60); PA-18 "105" (Special) s/n all (When equipped with wheel
A		IVIAIII	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-60);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
А			wheel 40-60);
		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with wheel 40-60):
A		Main	PA-18 "150"* s/n 18-3781 thru 18-8309025 (When
A		Main	equipped with wheel 40-60);
^		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped with wheel 40-60);
Α		Main	PA-18A s/n all (When equipped with wheel 40-60);
A		Main	PA-18A "135" s/n all (When equipped with wheel 40-60);
A		Main	PA-18A "150"* s/n 18-3781 thru 18-8309025 (When
			equipped with wheel 40-60);
A		Main	PA-20 s/n all (When equipped with wheel 40-60);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-60);
Α		Main	PA-20 "135" s/n all (When equipped with wheel 40-60);
^A MC153-	00300 153-00300, 755-929, A39070	Main	J-3 s/n all (When equipped with wheel 40-84);
A		Main	J-3 s/n all (When equipped with wheel 40-84B);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-84);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B);
Α		Main	J3C-40 s/n all (When equipped with wheel 40-84);
A		Main	J3C-40 s/n all (When equipped with wheel 40-84B);
Α		Main	J3C-50 s/n all (When equipped with wheel 40-84);
A		Main	J3C-50 s/n all (When equipped with wheel 40-84B);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84B);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-84);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
Δ		Main	(When equipped with wheel 40-84B);
^		Main	J3C-65S s/n all (When equipped with wheel 40-84);
Α Δ		Main	J3C-65S s/n all (When equipped with wheel 40-84B);
Α Δ		Main	J3F-50 s/n all (When equipped with wheel 40-84);
Α		Main	J3F-50 s/n all (When equipped with wheel 40-84B);
Α		Main	J3F-50S s/n all (When equipped with wheel 40-84);
Α		Main	J3F-50S s/n all (When equipped with wheel 40-84B);
Α .		Main	J3F-60 s/n all (When equipped with wheel 40-84);
Α .		Main	J3F-60 s/n all (When equipped with wheel 40-84B);
Α .		Main	J3F-60S s/n all (When equipped with wheel 40-84);
Α		Main	J3F-60S s/n all (When equipped with wheel 40-84B);



^A MC153-00300	153-00300, 755-929,		13E-65 (Army L-41)) e/n all (Mhan aguinnad with whad
	A39070	Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84);
А		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84B);
A		Main	J3F-65S s/n all (When equipped with wheel 40-84);
A		Main	J3F-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3L s/n all (When equipped with wheel 40-84);
A		Main	J3L s/n all (When equipped with wheel 40-84B);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84B);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3L-S s/n all (When equipped with wheel 40-84);
A		Main	J3L-S s/n all (When equipped with wheel 40-84B);
A		Main	J3P s/n all (When equipped with wheel 40-84);
A		Main	J3P s/n all (When equipped with wheel 40-84B);
A		Main	PA-11 s/n all (When equipped with wheel 40-84);
A		Main	PA-11 s/n all (When equipped with wheel 40-84B);
A		Main	PA-11S s/n all (When equipped with wheel 40-84);
A		Main	PA-11S s/n all (When equipped with wheel 40-84B);
A		Main	PA-18 s/n all (When equipped with wheel 40-84);
A		Main	PA-18 s/n all (When equipped with wheel 40-84B);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel 40-84B);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with wheel 40-84);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with wheel 40-84B):
A		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When equipped with wheel 40-84B);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped with wheel 40-84B);
A		Main	PA-18A s/n all (When equipped with wheel 40-84);
A		Main	PA-18A s/n all (When equipped with wheel 40-84B);
		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);



Rev Part Number	Replaces	Location	Model and Serial Number Range
^A MC153-00300	153-00300, 755-929,	Main	PA-18A "135" s/n all (When equipped with wheel
	A39070		40-84B);
A		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "150" s/n all (When equipped with wheel
Ā			40-84B);
A A		Main	PA-20 s/n all (When equipped with wheel 40-84);
A		Main	PA-20 s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
A .		Main	PA-22 s/n all (When equipped with wheel 40-84);
A .		Main	PA-22 s/n all (When equipped with wheel 40-84B);
A .		Main	PA-22-108 s/n all (When equipped with wheel 40-84);
A .		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
A .		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
A .		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
A .		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A .		Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
A .		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A .		Main	PA-22-160 s/n all (When equipped with wheel 40-84B);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
_			with wheel 40-84);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
_			with wheel 40-84B);
A		Main	PA-24-400* s/n 24-130 thru 26-148 (When equipped with
_			wheel 40-90);
A		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
_			equipped with wheel 40-90A);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
_			with wheel 40-90A);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
_			equipped with wheel 40-84);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
_			equipped with wheel 40-84B);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
_			equipped with wheel 40-84);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
_			equipped with wheel 40-84B);
A		Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
			wheel 40-90);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A .		Main	PA-32-260 s/n all (When equipped with wheel 40-90);
A .		Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
A .		Main	PA-32-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90);



г.	Deat Novels	Denlass:	Locatio-	Madel and Cariel Number Deve
Rev A	Part Number MC153-00300	Replaces 153-00300, 755-929,	<u>Location</u> Main	Model and Serial Number Range PA-32-300 s/n all (When equipped with wheel 40-90A);
	WO 133-00300	A39070	IVICIII	1 A-32-300 3/11 all (Which equipped with which 40-30A),
А		A39070	Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
				equipped with wheel 40-120C);
A			Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
				equipped with wheel 40-90A);
A			Main	PA-32-301FT s/n all (When equipped with wheel
				40-120C);
Α			Main	PA-32-301T s/n all (When equipped with wheel 40-120C);
Α			Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
A			Main	PA-32-301XTC s/n all (When equipped with wheel
				40-120C);
Α .			Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
Α .			Main	PA-32R-300 s/n all (When equipped with wheel 40-90A);
A			Main	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
A			Main	with wheel 40-90A);
			Main	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
A			Main	with wheel 40-120C); PA-32R-301T* s/n 3229001 thru 3229003 (When
			Main	equipped with wheel 40-120C);
А			Main	PA-32R-301T* s/n 3257001 thru 3257999 (When
			Main	equipped with wheel 40-120C);
А			Main	PA-32RT-300 s/n all (When equipped with wheel 40-120);
А			Main	PA-32RT-300 s/n all (When equipped with wheel
				40-120C);
A			Main	PA-32RT-300 s/n all (When equipped with wheel
				40-90A);
Α			Main	PA-32RT-300T s/n all (When equipped with wheel
				40-120);
A			Main	PA-32RT-300T s/n all (When equipped with wheel
				40-120C);
Α			Main	PA-32RT-300T s/n all (When equipped with wheel
A			Main	40-90A);
A			Main Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
A			Main	PA-34-200 s/n all (When equipped with wheel 40-90); PA-34-200 s/n all (When equipped with wheel 40-90A);
A			Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
А			Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
А			Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
				equipped with wheel 40-120C);
А			Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
				equipped with wheel 40-90A);
A			Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
				with wheel 40-120C);
A			Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
				with wheel 40-90A);



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC153-00300	153-00300, 755-929,	<u>Location</u> Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
WIG 100 00000	A39070	Man	with wheel 40-120C);
A	A39070	Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
		IVIAIII	
A		Main	with wheel 40-90A);
		iviaiii	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
A		Main	with wheel 40-120C);
		Main	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
A		Main	with wheel 40-120C);
A		Main	PA-39 s/n all (When equipped with wheel 40-90);
^		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-120);
A		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-120C);
A		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-90A);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120C);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-90A);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120C);
A		Main	PA-44-180T s/n all (When equipped with wheel 40-120);
A		Main	PA-44-180T s/n all (When equipped with wheel 40-120C);
A		Main	PA-44-180T s/n all (When equipped with wheel 40-90A);
A		Main	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-120C);
A		Main	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-120C);
A		Main	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-120C);
A		Main	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
			(When equipped with wheel 40-120C);
A		Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
			wheel 40-142);
A		Main	PA-46-500TP (w/o G1000) s/n all (When equipped with
		TVI CALL	wheel 40-142);
A		Main	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-46R-350T (w/o G1000) s/n all (When equipped with
		Mail	wheel 40-120C);
			writed 40-1200 <i>)</i> ,
1			



Rev Part Number MC153-00300	Replaces 153-00300, 755-929,	<u>Location</u> Main	Model and Serial Number Range PA-60-600 s/n all (When equipped with wheel 40-124);
	A39070		
A		Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
			equipped with wheel 40-124);
A .		Main	PA-60-601 s/n all (When equipped with wheel 40-124);
A		Main	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
A		Main	equipped with wheel 40-124);
		Main	PA-60-601P s/n all (When equipped with wheel 40-124);
		Main	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-124);
A		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
A		Main	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-124);
^A MC153-00400	153-004, 153-00400, 153-4, 3022, 752-829,	Main	J-3 s/n all (When equipped with wheel 40-84);
	755-999		
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-84);
A		Main	J3C-40 s/n all (When equipped with wheel 40-84);
Α		Main	J3C-50 s/n all (When equipped with wheel 40-84);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
A		Main	(When equipped with wheel 40-84);
A		Main Main	J3C-65S s/n all (When equipped with wheel 40-84); J3F-50 s/n all (When equipped with wheel 40-84);
A		Main	J3F-50S s/n all (When equipped with wheel 40-84);
A		Main	J3F-60 s/n all (When equipped with wheel 40-84);
A		Main	J3F-60S s/n all (When equipped with wheel 40-84);
Α		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84);
A		Main	J3F-65S s/n all (When equipped with wheel 40-84);
A		Main	J3L s/n all (When equipped with wheel 40-84);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84);
A		Main	J3L-S s/n all (When equipped with wheel 40-84);
A		Main	J3P s/n all (When equipped with wheel 40-84);
A		Main	PA-11 s/n all (When equipped with wheel 40-84);
Α		Main	PA-11S s/n all (When equipped with wheel 40-84);
Α		Main	PA-18 s/n all (When equipped with wheel 40-84);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel 40-84);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with wheel 40-84);



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC153-00400	153-004, 153-00400,	Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
	153-4, 3022, 752-829, 755-999		wheel 40-84);
A	733-333	Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
A		Main	with wheel 40-84);
A		Main	PA-18A s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-22 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A		Main	PA-23 s/n all (When equipped with wheel 3080A (40-3));
•		Main	PA-23-160 s/n all (When equipped with wheel 3080A
A		N 4 = :	(40-3));
·		Main	PA-23-235 s/n all (When equipped with wheel 3080B
A		N 4 . * ·	(40-4));
		Main	PA-23-235 s/n all (When equipped with wheel 40-131);
^		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-3737 (When
A		N 4 . * ·	equipped with wheel 3080B (40-4));
^		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-7554149
À			(When equipped with wheel 40-131);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-3738 thru 27-7554137
À			(When equipped with wheel 3080D (40-116));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554141 thru
			27-7554149 (When equipped with wheel 3080D (40-116));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554150 thru
			27-8154030 (When equipped with wheel 40-131);
A		Main	PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped
			with wheel 3080B (40-4));
A		Main	PA-E23-250* s/n 27-2505 thru 27-7554149 (When
			equipped with wheel 40-131);
A		Main	PA-E23-250* s/n 27-3738 thru 27-7554137 (When
			equipped with wheel 3080D (40-116));
A		Main	PA-E23-250* s/n 27-7554141 thru 27-7554149 (When
			equipped with wheel 3080D (40-116));
A		Main	PA-E23-250* s/n 27-7554150 thru 27-7554168 (When
			equipped with wheel 40-131);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
			with wheel 40-84);



ev Part Number MC153-00400	Replaces 153-004, 153-00400,	<u>Location</u> Main	Model and Serial Number Range PA-24-400* s/n 24-130 thru 26-148 (When equipped wit
	153-4, 3022, 752-829,		wheel 40-90);
	755-999		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
4		Main	PA-25-235* s/n 25-4172 thru 25-8156024 (When
			equipped with wheel 40-84A);
		Main	PA-25-260* s/n 25-4415 thru 25-8156024 (When
			equipped with wheel 40-84A);
		Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
			equipped with wheel 40-86);
		Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
			equipped with wheel 40-86B);
		Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86);
		Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86B);
		Main	PA-28-151 s/n all (When equipped with wheel 40-86B);
		Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86);
		Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86B);
		Main	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			with wheel 40-86B);
		Main	PA-28-161* s/n 2841001 thru 2841365 (When equipped
			with wheel 40-86B);
		Main	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-86B);
		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86);
		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86B);
		Main	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-86B);
		Main	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-86B);
		Main	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-86B);
		Main	PA-28-201T s/n all (When equipped with wheel 40-86B)
		Main	PA-28-235* s/n 28-10487 thru 28-7710089 (When
			equipped with wheel 40-86);
		Main	PA-28-235* s/n 28-10487 thru 28-7710089 (When
			equipped with wheel 40-86B);
		Main	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-86B);
		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
			equipped with wheel 40-90A);



Rev	Part Number MC153-00400	Replaces 153-004, 153-00400,	<u>Location</u> Main	Model and Serial Number Range PA-28-236* s/n 2811001 thru 2811050 (When equipped
	WIO 100 00+00	153-4, 3022, 752-829,	Wall	with wheel 40-86B);
		755-999		with wheel 40-00D),
А		700 000	Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
				with wheel 40-90A);
А			Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
				equipped with wheel 40-84);
Α			Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
				equipped with wheel 40-86);
Α			Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
				equipped with wheel 40-86B);
Α			Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
				equipped with wheel 40-84);
Α			Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
				equipped with wheel 40-86);
A			Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
_				equipped with wheel 40-86B);
A			Main	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
١.				equipped with wheel 40-86B);
A			Main	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
A			N.4 - :	with wheel 40-86B);
_ ^			Main	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
A			Main	with wheel 40-86B);
,			Main	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
A			Main	(When equipped with wheel 40-86B);
			iviaiii	PA-28R-201T* s/n 2803001 thru 2803012 (When
А			Main	equipped with wheel 40-86B); PA-28RT-201 s/n all (When equipped with wheel
			Wall	40-86B);
А			Main	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
				(When equipped with wheel 40-86B);
A			Main	PA-28RT-201T* s/n 2831001 thru 2831038 (When
				equipped with wheel 40-86B);
А			Main	PA-30* s/n 30-2 thru 30-845 (When equipped with wheel
				40-34);
A			Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
				wheel 40-90);
Α			Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A			Main	PA-32-260 s/n all (When equipped with wheel 40-90);
Α			Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
A			Main	PA-32-300 s/n all (When equipped with wheel 40-120);
Α .			Main	PA-32-300 s/n all (When equipped with wheel 40-90);
Α .			Main	PA-32-300 s/n all (When equipped with wheel 40-90A);
Α			Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
				equipped with wheel 40-120C);



ev Part Number MC153-00400	Replaces 153-004, 153-00400,	<u>Location</u> Main	Model and Serial Number Range PA-32-301* s/n 32-8006002 thru 32-8606023 (When
	153-4, 3022, 752-829,		equipped with wheel 40-90A);
A	755-999	Main	DA 22 201FT o/p all /M/ban aguinned with wheel
		IVIAIII	PA-32-301FT s/n all (When equipped with wheel 40-120C);
		Main	PA-32-301T s/n all (When equipped with wheel 40-120C)
		Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
		Main	PA-32-301XTC s/n all (When equipped with wheel
			40-120C);
		Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
		Main	PA-32R-300 s/n all (When equipped with wheel 40-90A);
		Main	PA-32R-301* s/n 3213001 thru 3213103 (When equippe
			with wheel 40-90A);
		Main	PA-32R-301* s/n 3246001 thru 3246999 (When equippe
			with wheel 40-120C);
		Main	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-120C);
		Main	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-120C);
		Main	PA-32RT-300 s/n all (When equipped with wheel 40-120
		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-120C);
		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-90A);
		Main	PA-32RT-300T s/n all (When equipped with wheel
		Main	40-120);
		Main	PA-32RT-300T s/n all (When equipped with wheel
		Main	40-120C);
		iviairi	PA-32RT-300T s/n all (When equipped with wheel 40-90A);
		Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
		Main	PA-34-200 s/n all (When equipped with wheel 40-90);
		Main	PA-34-200 s/n all (When equipped with wheel 40-90A);
		Main	PA-34-200T s/n all (When equipped with wheel 40-1200
		Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-120C);
		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-90A);
		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-120C);
		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-90A);
		Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-120C);



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC153-00400	153-004, 153-00400,	Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
	153-4, 3022, 752-829, 755-999		with wheel 40-90A);
A	700 000	Main	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
		Wildin	with wheel 40-120C);
A		Main	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
		Widin	with wheel 40-120C);
A		Main	PA-39 s/n all (When equipped with wheel 40-90);
A		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		Mairi	equipped with wheel 40-120);
A		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		Iviaiii	`
Α		Main	equipped with wheel 40-120C);
		IVIAIII	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
Α		Main	equipped with wheel 40-90A);
		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
Α		Main	with wheel 40-120);
		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
A		N.4 :	with wheel 40-120C);
^		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
_			with wheel 40-90A);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120C);
A .		Main	PA-44-180T s/n all (When equipped with wheel 40-120);
A		Main	PA-44-180T s/n all (When equipped with wheel 40-120C);
A .		Main	PA-44-180T s/n all (When equipped with wheel 40-90A);
A		Main	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-120C);
A		Main	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-120C);
A		Main	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-120C);
A		Main	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
			(When equipped with wheel 40-120C);
A		Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
			wheel 40-142);
A		Main	PA-46-500TP (w/o G1000) s/n all (When equipped with
			wheel 40-142);
A		Main	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-120C);



Rev Part Number	Replaces	Location	Model and Serial Number Range
^A MC153-00500	153-00500	Main	PA-22 s/n all (When equipped with wheel 3040 (40-6));
A .		Aux	PA-22 s/n all (When equipped with wheel 38501 (40-8));
A .		Main	PA-22 s/n all (When equipped with wheel 40-28);
A		Aux	PA-22-108 s/n all (When equipped with wheel 38501
A		Main	(40-8)); PA-22-108 s/n all (When equipped with wheel 40-28);
A		Main	PA-22-106 S/n all (When equipped with wheel 40-26);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-28);
A		Main	PA-22-130 s/n all (When equipped with wheel 40-28);
A		Aux	PA-23 s/n all (When equipped with wheel 38501 (40-8));
A		Aux	PA-23-160 s/n all (When equipped with wheel 38501
		Aux	(40-8));
A		Aux	PA-23-235 s/n all (When equipped with wheel 38501
			(40-8));
A		Aux	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-4822 (When
			equipped with wheel 38501 (40-8));
Α		Aux	PA-E23-250* s/n 27-2505 thru 27-4822 (When equipped
			with wheel 38501 (40-8));
A		Main	PA-24* s/n 24-1 thru 24-3306 (When equipped with
			wheel 3070 (40-5));
Α		Aux	PA-24 s/n all (When equipped with wheel 38501 (40-8));
Α		Main	PA-24* s/n 24-3307 thru 24-3687 (When equipped with
			wheel 40-58);
A		Main	PA-24-250* s/n 24-1 thru 24-3306 (When equipped with
			wheel 3070 (40-5));
A		Aux	PA-24-250* s/n 24-1 thru 24-3306 (When equipped with
			wheel 38501 (40-8));
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
			with wheel 40-58);
A		Aux	PA-24-260* s/n 24-4000 thru 24-5019 (When equipped
_			with wheel 38501 (40-8));
A		Aux	PA-24-260* s/n 24-5021 thru 24-5023 (When equipped
_		_	with wheel 38501 (40-8));
A		Aux	PA-24-400 s/n all (When equipped with wheel 38501
			(40-8));
A		Main	PA-25 s/n all (When equipped with wheel 3070 (40-5));
A		Main	PA-25-235* s/n 25-2000 thru 25-4171 (When equipped
A		NA . *	with wheel 40-61);
^		Main	PA-28-140* s/n 28-20002 thru 28-20520 (When equipped
A		Δ	with wheel 40-28);
•		Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
A		Main	equipped with wheel 38501 (40-8));
•		Main	PA-28-150* s/n 28-1 thru 28-1760 (When equipped with
A		Ausz	wheel 40-28);
		Aux	PA-28-150 s/n all (When equipped with wheel 38501
			(40-8));



	rt Number 0153-00500	Replaces 153-00500	<u>Location</u> Main	Model and Serial Number Range PA-28-160* s/n 28-1 thru 28-1760 (When equipped with
1010	7100 00000	100 00000	Main	wheel 40-28);
A			Aux	PA-28-160 s/n all (When equipped with wheel 38501
			Nux	(40-8));
A			Main	PA-28-180* s/n 28-671 thru 28-1760 (When equipped
			iviaiii	
A			Aux	with wheel 40-28);
			Aux	PA-28-180* s/n 28-671 thru 28-7205243 (When equipped
4			Main	with wheel 38501 (40-8));
•			Main	PA-28-235* s/n 28-10003 thru 28-10486 (When equipped
A			A	with wheel 40-58);
•			Aux	PA-28-235* s/n 28-10003 thru 28-7210019 (When
				equipped with wheel 38501 (40-8));
A			Aux	PA-30* s/n 30-2 thru 30-2000 (When equipped with
_				wheel 38501 (40-8));
A			Aux	PA-32-260* s/n 32-1 thru 31-7200029 (When equipped
				with wheel 38501 (40-8));
A			Aux	PA-32-300* s/n 32-40000 thru 32-7240100 (When
				equipped with wheel 38501 (40-8));
4			Aux	PA-34-200* s/n 34-7250001 thru 34-7250216 (When
				equipped with wheel 38501 (40-8));
4			Aux	PA-39* s/n 39-1 thru 39-148 (When equipped with wheel
				38501 (40-8));
^a MC	2153-00800	153-00800, 153-30048, 153-8, 756-007, 762-560, A-30048	Aux	PA-28-151 s/n all (When equipped with wheel 40-77);
Α.		A-300 4 0	Aux	PA-28-151 s/n all (When equipped with wheel 40-77B);
4			Aux	PA-28-151 s/n all (When equipped with wheel D-30500);
			Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			Aux	with wheel 40-77);
١			Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			, , , , , , , , , , , , , , , , , , , ,	with wheel 40-77B);
١			Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			Tux	with wheel D-30500);
١			Aux	PA-28-161* s/n 2841001 thru 2841365 (When equipped
		Nux	with wheel 40-77B);	
١			Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			Aux	with wheel 40-77);
4			Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			Aux	
A			Aux	with wheel 40-77B); PA-28-161* s/n 2842001 thru 2842999 (When equipped
			Λυλ	with wheel D-30500);
4			Aux	PA-28-201T s/n all (When equipped with wheel 40-77);
			Aux	PA-28-201T s/n all (When equipped with wheel 40-77B);
A				, , , , , , , , , , , , , , , , , , , ,
A A			Διιχ	PA-28-2011 s/n all (When equipped with wheel D-30500):
			Aux	PA-28-201T s/n all (When equipped with wheel D-30500);



153-30048, 153-8, 756-007, 762-560, A-30048 A	Rev Part Number MC153-00800	Replaces 153-00800,	<u>Location</u> Aux	Model and Serial Number Range PA-28R-180 s/n all (When equipped with wheel 40-77);
Aux PA-28R-180 s/n all (When equipped with wheel 40-77A); Aux PA-28R-180 s/n all (When equipped with wheel 40-77B); PA-28R-180 s/n all (When equipped with wheel 40-77B); PA-28R-200 s/n all (When equipped with wheel 40-77B); PA-28R-200 s/n all (When equipped with wheel 40-77A); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-201 s/n all (When		153-30048, 153-8, 756-007, 762-560,		,,
A Lux PA-28R-180 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-180 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77F); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77F); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-200 s/n all (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-777); A Lux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-7373002 thru 28R-7837317 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2844001 thru 2834999 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 2844001 thru 28R-7803373 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); A Lux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); A Lux PA-28R-201T s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Lux PA-28R-201T s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Lux PA-28R-201T s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Lux PA-28R-201T s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Lux PA-28R-201T s/n 2803001 thr	A	A-300 4 0	Aux	PA-28R-180 s/n all (When equipped with wheel 40-77A);
Aux PA-28R-180 s/n all (When equipped with wheel D-30500); Aux PA-28R-200 s/n all (When equipped with wheel 40-777); Aux PA-28R-200 s/n all (When equipped with wheel 40-778); Aux PA-28R-200 s/n all (When equipped with wheel 40-778); Aux PA-28R-200 s/n all (When equipped with wheel 40-778); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-703001 thru 2803012 (Wh	A		Aux	
D-30500 ;	A			
Aux PA-28R-200 s/n all (When equipped with wheel 40-77); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 284-7001 thru 284-780373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Au				· · · ·
Aux PA-28R-200 s/n all (When equipped with wheel 40-77A); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77T); Aux PA-28R-201 s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28R-7037002 thru 28R-7837317 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 284001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28470001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28470001 thru 2847803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28470001 thru 2847803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28470001 thru 2847803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 28470001 thru 2847803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 288-7703001 thru 288-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 288-703001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201 s/n 2803001 thru 2803012 (A		Aux	<i>''</i>
Aux PA-28R-200 s/n all (When equipped with wheel 40-77B); Aux PA-28R-200 s/n all (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-737002 thru 28R-7837317 (When equipped with wheel do-77); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel 40-77D); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77D); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77D); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77D); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 284-7803373 (When equipped with wheel 40-77C); Aux PA-28R-201* s/n 284-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-703001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B);	A			, , , , , , , , , , , , , , , , , , , ,
Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-37B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-37B); Aux PA-28R-201* s/n 288-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 30-30500); Aux PA-28R-201* s/n 280-3001 thru 28R-7803373 (When equipped with wheel 30-30500); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 280-3001 thru 280-3012 (Whenequipped with wheel 40-77B);	A		Aux	
Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where equipped with wheel P-350500); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77T); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803073 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803073 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (Whenequipped with wheel 40-77B); Aux PA-28R-201* s/n all (Whenequipped with wheel 40-77); Aux PA-28R-201* s/n all (Whenequipped with wheel 40-77);	A		Aux	PA-28R-200 s/n all (When equipped with wheel
Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where quipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Where quipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77F); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-703001 thru 28R-7803373 (When equipped with wheel 40-77F); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T);	A		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
equipped with wheel 40-77B);	A		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77); A lux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 288-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A lux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B);				equipped with wheel 40-77B);
Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 288-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B);	A		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 28R-7803373 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77C);				equipped with wheel D-30500);
Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel D-30500);	A		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
Aux PA-28R-201* s/n 2837001 (Image equipped with wheel 40-77B); Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-777); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B);				with wheel 40-77);
Aux PA-28R-201* s/n 2837001 thru 2837061 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-778); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-2011* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500);	A		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipper with wheel D-30500); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipper with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipper with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipper with wheel D-30500); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500);				with wheel 40-77B);
Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-2011* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-2011* s/n all (When equipped with wheel 40-77);	A		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77T); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B);				with wheel D-30500);
Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel 40-77B); Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500);	Α		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
Aux				· ·
Aux PA-28R-201* s/n 2844001 thru 2844999 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel Aux PA-28R-201T* s/n 2803012 (When equipped with wh	A		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 When equipped with wheel 40-77);				• •
Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77);	A		Aux	
(When equipped with wheel 40-77); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel	A		Διιχ	
Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel			Tux	
A Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); A Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); A Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
Aux PA-28R-201T* s/n 28R-7703001 thru 28R-7803373 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28R-201T* s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel			7 (0)/	
A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); A Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); A Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); A Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel				
equipped with wheel 40-77); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel				·
equipped with wheel 40-77B); Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
Aux PA-28R-201T* s/n 2803001 thru 2803012 (When equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel				· ·
equipped with wheel D-30500); Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
Aux PA-28RT-201 s/n all (When equipped with wheel 40-77); Aux PA-28RT-201 s/n all (When equipped with wheel			-	· ·
A Aux PA-28RT-201 s/n all (When equipped with wheel	A		Aux	
\ 111	A			, , , , , , , , , , , , , , , , , , , ,
40-778):			-	40-77B);



Rev Part Number	<u>Replaces</u>	<u>Location</u>	Model and Serial Number Range
^A MC153-00800	153-00800,	Aux	PA-28RT-201 s/n all (When equipped with wheel
	153-30048, 153-8,		D-30500);
	756-007, 762-560,		
	A-30048		
A		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77);
A		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77B);
A		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel D-30500);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-77);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
		Nux	equipped with wheel 40-77B);
A		Aux	
		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
A		A	equipped with wheel D-30500);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
Ā			equipped with wheel 40-77);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-77B);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel D-30500);
Α		Aux	PA-32-301T s/n all (When equipped with wheel 40-77);
A		Aux	PA-32-301T s/n all (When equipped with wheel 40-77B);
A		Aux	PA-32-301T s/n all (When equipped with wheel D-30500);
A		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77);
A		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77B);
A		Aux	PA-32R-300 s/n all (When equipped with wheel
			D-30500);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-77);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-77B);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
		, tan	with wheel D-30500);
A		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
		Aux	
A		Aux	with wheel 40-77);
		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
A		A	with wheel 40-77B);
		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
٨			with wheel D-30500);
A		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-77);
А		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-77B);



ev Part Number MC153-00800	Replaces 153-00800,	<u>Location</u> Aux	Model and Serial Number Range PA-32R-301T* s/n 3229001 thru 3229003 (When
	153-30048, 153-8,		equipped with wheel D-30500);
	756-007, 762-560,		
	A-30048	Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-77);
		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-77B);
		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel D-30500);
		Aux	PA-32RT-300 s/n all (When equipped with wheel 40-77);
		Aux	PA-32RT-300 s/n all (When equipped with wheel
			40-77B);
		Aux	PA-32RT-300 s/n all (When equipped with wheel D-30500);
		Aux	PA-32RT-300T s/n all (When equipped with wheel 40-77)
		Aux	PA-32RT-300T s/n all (When equipped with wheel
			40-77B);
		Aux	PA-32RT-300T s/n all (When equipped with wheel
			D-30500);
		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-77B);
		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-77B);
		Aux	PA-34-220T* s/n 3448001 thru 3448037 (When equipped
			with wheel 40-77B);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77B);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77C);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
		M = :	equipped with wheel D-30500);
		Main	PA-38-112 s/n all (When equipped with wheel 40-78B);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		Ausz	equipped with wheel 40-77);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		Auv	equipped with wheel 40-77B);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		Aux	equipped with wheel D-30500); PA-44-180* s/n 4495001 thru 4495013 (When equipped
		ΛuΛ	, , , , , , , , , , , , , , , , , , , ,
		Aux	with wheel 40-77); PA-44-180* s/n 4495001 thru 4495013 (When equipped
		Aux	with wheel 40-77B);
			WILL WITCH 40-11 D1.



Rev Part Number MC153-00800	<u>Replaces</u> 153-00800,	<u>Location</u> Aux	Model and Serial Number Range PA-44-180* s/n 4495001 thru 4495013 (When equipped
	153-30048, 153-8,		with wheel D-30500);
	756-007, 762-560,		,
	A-30048		
A		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-77);
A		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-77B);
A		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel D-30500);
A		Aux	PA-44-180T s/n all (When equipped with wheel 40-77);
A		Aux	PA-44-180T s/n all (When equipped with wheel 40-77B);
A		Aux	PA-44-180T s/n all (When equipped with wheel D-30500)
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-77);
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-77B);
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel D-30500);
A		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-77);
A		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-77B);
A		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel D-30500);
A		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-77);
A		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
A		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel D-30500);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-77);
4		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-77B);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel D-30500);
A		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
			(When equipped with wheel 40-77);
A		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		_	(When equipped with wheel 40-77B);
A		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		_	(When equipped with wheel D-30500);
A		Aux	PA-46-500TP (w/ G1000) s/n all (When equipped with
			wheel 40-77G);



Rev Part Number MC153-00800	Replaces 153-00800,	<u>Location</u> Aux	Model and Serial Number Range PA-46-500TP (w/o G1000) s/n all (When equipped with
	153-30048, 153-8, 756-007, 762-560,		wheel 40-77G);
	A-30048		
Α		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-77);
Α		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with wheel D-30500);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with wheel 40-77);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
		, tux	wheel 40-77B);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
		, lan	wheel D-30500);
^A MC153-00900	153-00900, 153-9, 755-964	Aux	PA-22 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-23 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-23-160 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-23-250 (Navy UO-1)* s/n 27-4823 thru 27-8154030
			(When equipped with wheel 40-76B);
A		Aux	PA-E23-250* s/n 27-4823 thru 27-7554168 (When
			equipped with wheel 40-76B);
A		Aux	PA-24-260* s/n 24-5020 thru 24-5034 (When equipped
			with wheel 40-76B);
A		Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
			equipped with wheel 40-76B);
A		Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
			equipped with wheel 40-76F);
A		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76B);
A		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76F);
A		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-56B or 40-56);
A		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-76F);
Α		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-56B or 40-56);
A		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-76F);
A		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-56B or 40-56);
			<i>"</i>



ev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
MC153-00900	153-00900, 153-9,	Aux	PA-28-235* s/n 28-7210020 thru 28-7710089 (When
	755-964		equipped with wheel 40-76B);
		Aux	PA-28-235* s/n 28-7210020 thru 28-7710089 (When
			equipped with wheel 40-76F);
		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-56);
		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-56);
		Aux	PA-30* s/n 39-152 thru 30-2000 (When equipped with
			wheel 40-76B);
		Aux	PA-31* s/n 31-5 thru 31-8112037 (When equipped with
			wheel 40-76B);
		Aux	PA-31* s/n 31-8112038 thru 31-8312019 (When equippe
			with wheel 40-140);
		Aux	PA-31-300* s/n 31-5 thru 31-8112037 (When equipped
			with wheel 40-76B);
		Aux	PA-31-300* s/n 31-8112038 thru 31-8312019 (When
			equipped with wheel 40-140);
		Aux	PA-31-325* s/n 31-7400990 thru 31-8112037 (When
			equipped with wheel 40-76B);
		Aux	PA-31-325* s/n 31-8112038 thru 31-8312019 (When
		7107	equipped with wheel 40-140);
		Aux	PA-31-350* s/n 31-5001 thru 31-8152087 (When
		7107	equipped with wheel 40-76B);
		Aux	PA-31-350* s/n 31-8152088 thru 31-8553002 (When
		Aux	equipped with wheel 40-140);
		Aux	PA-31-350 (T1020) s/n all (When equipped with wheel
		Aux	40-140);
		Aux	PA-31P s/n all (When equipped with wheel 40-140);
		Aux	PA-31P s/n all (When equipped with wheel 40-76B);
		Aux	PA-31P-350 s/n all (When equipped with wheel 40-140);
		Aux	PA-31T s/n all (When equipped with wheel 40-140);
		Aux	PA-31T2 s/n all (When equipped with wheel 40-140);
		Aux	PA-31T3 (T1040) s/n all (When equipped with wheel
		Δ	40-140);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
			equipped with wheel 40-56B or 40-56);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
			equipped with wheel 40-76B);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
		_	equipped with wheel 40-76F);
		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-56B or 40-56);
		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-76B);



Rev Part	<u>Number</u> 53-00900	Replaces	<u>Location</u>	Model and Serial Number Range
IVICI	JJ-00900	153-00900, 153-9,	Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
A		755-964	Ausz	equipped with wheel 40-76F);
**			Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
A			A	equipped with wheel 40-56B or 40-56);
^			Aux	PA-32-301FT s/n all (When equipped with wheel 40-56B
Α			Δ.	or 40-56);
^			Aux	PA-32-301T s/n all (When equipped with wheel 40-56B or
				40-56);
Α			Aux	PA-32-301XTC s/n all (When equipped with wheel
				40-56B or 40-56);
Α			Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
			_	equipped with wheel 40-76B);
Α			Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
				equipped with wheel 40-76F);
Α			Aux	PA-34-200T s/n all (When equipped with wheel 40-56B or
_			_	40-56);
Α .			Aux	PA-34-200T s/n all (When equipped with wheel 40-76F);
Α			Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
				equipped with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
				with wheel 40-56B or 40-56);
Α			Main	PA-36-285 s/n all (When equipped with wheel 40-101);
Α			Main	PA-36-300 s/n all (When equipped with wheel 40-101);
Α			Main	PA-36-375 s/n all (When equipped with wheel 40-101);
Α			Aux	PA-38-112 s/n all (When equipped with wheel 40-56);
Α			Main	PA-38-112 s/n all (When equipped with wheel 40-59D);
Α			Aux	PA-42 s/n all (When equipped with wheel 40-140);
Α			Aux	PA-42-1000 s/n all (When equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-5501003 thru 42-5501039 (When
				equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-8301001 thru 42-8301002 (When
				equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-5501040 thru 42-5501060 (When
				equipped with wheel 40-140);
A			Aux	PA-42-720R s/n all (When equipped with wheel 40-140);
A			Main	PA-60-600 s/n all (When equipped with wheel 40-124);
A			Aux	PA-60-600 s/n all (When equipped with wheel 40-76B);
A			Aux	PA-60-600 s/n all (When equipped with wheel 40-76F);
Α			Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
				equipped with wheel 40-124);



755-984	Rev Part Number MC153-00900	Replaces 153-00900, 153-9,	<u>Location</u> Aux	Model and Serial Number Range PA-60-600 (Ted Smith Aerostar 600) s/n all (When
Aux PA-60-601 (Fed Smith Aerostar 600) s/n all (When equipped with wheel 40-124); A Aux PA-60-601 s/n all (When equipped with wheel 40-124); A Aux PA-60-601 s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 (Fed Smith Aerostar 601) s/n all (When equipped with wheel 40-124); A Aux PA-60-601 (Fed Smith Aerostar 601) s/n all (When equipped with wheel 40-124); A Aux PA-60-601 (Fed Smith Aerostar 601) s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 (Fed Smith Aerostar 601) s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P (Fed Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); A Aux PA-60-601 P (Fed Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B); A Aux PA-60-602 P s/n all (When equipped with wheel 40-76B)	WO 133-00300		Aux	
Main	A	755-964	Aux	, , , , , , , , , , , , , , , , , , , ,
Main			Aux	
Aux PA-60-601 s'n all (When equipped with wheel 40-76B); Aux PA-60-601 s'n all (When equipped with wheel 40-76B); Aux PA-60-601 s'n all (When equipped with wheel 40-76B); Aux PA-60-601 (Ted Smith Aerostar 601) s'n all (When equipped with wheel 40-124); Aux PA-60-601 (Ted Smith Aerostar 601) s'n all (When equipped with wheel 40-76B); Aux PA-60-601 (Ted Smith Aerostar 601) s'n all (When equipped with wheel 40-76B); Aux PA-60-601 F s'n all (When equipped with wheel 40-124); Aux PA-60-601 P s'n all (When equipped with wheel 40-76B); Aux PA-60-601 P s'n all (When equipped with wheel 40-76B); Aux PA-60-601 P (Ted Smith Aerostart 601 P) s'n all (When equipped with wheel 40-76B); Aux PA-60-601 P (Ted Smith Aerostart 601 P) s'n all (When equipped with wheel 40-76B); Aux PA-60-601 P (Ted Smith Aerostart 601 P) s'n all (When equipped with wheel 40-76B); Aux PA-60-601 P (Ted Smith Aerostart 601 P) s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-76B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-602 P s'n all (When equipped with wheel 40-84B); Aux PA-60-6	Δ		N 4 = :	
Aux PA-60-601 sin all (When equipped with wheel 40-76F); A haux PA-60-601 (Ted Smith Aerostar 601) sin all (When equipped with wheel 40-76F); A haux PA-60-601 (Ted Smith Aerostar 601) sin all (When equipped with wheel 40-76F); A haux PA-60-601 (Ted Smith Aerostar 601) sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-601 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-76F); A haux PA-60-602 P sin all (When equipped with wheel 40-84B); A haux PA-60-602 P sin all (When equipped with wheel 40-84B); A haux PA-60-602 P sin all (When equipped with wheel 40-84B); A haux PA-60-602 P sin all (When equipped with wheel 40-84B); A haux PA-60-602 P sin all (When equipped with wheel 40-84B); A haux PA-60-602 P sin all (W				
Main				
Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-124); Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-76F); Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-76F); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F);				
Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-76B); Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-124); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76P); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with	A		Main	, , , , , , , , , , , , , , , , , , , ,
Aux PA-60-601 (Ted Smith Aerostar 601) s/n all (When equipped with wheel 40-76F); A Main PA-60-601P s/n all (When equipped with wheel 40-124); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-124); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostar 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/	A		Aux	, , ,
Main PA-60-601P s/n all (When equipped with wheel 40-124); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-124); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P	A		Aux	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-124); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P s/n all (When equipped with wheel 40-84B); Aux PA-60-602	٨		NA = i	
Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Alian PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-124); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n				
Main PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-124); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (Whe				
Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B				
Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Sm	A		Main	
Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all				7.
Aux PA-60-601P (Ted Smith Aerostart 601P) s/n all (When equipped with wheel 40-76F); Main PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Main PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When	A		Aux	, , , , , , , , , , , , , , , , , , , ,
Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (, , , ,
Main PA-60-602P s/n all (When equipped with wheel 40-124); Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (Wh	A		Aux	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
Aux PA-60-602P s/n all (When equipped with wheel 40-76B); Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Main PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equippe				equipped with wheel 40-76F);
Aux PA-60-602P s/n all (When equipped with wheel 40-76F); Main PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Main J-3 s/n all (When equipped with wheel 40-84); Main J-3 s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);	A		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
Main PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smit	A		Aux	PA-60-602P s/n all (When equipped with wheel 40-76B);
Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aeros	A		Aux	PA-60-602P s/n all (When equipped with wheel 40-76F);
equipped with wheel 40-124); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped w	A		Main	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-84B); Aux PA-60-				
Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); A MC153-01500 153-01500, 153-15, Main J-3 s/n all (When equipped with wheel 40-84); A MC153-01500 153-01500, 153-15, Main J-3 s/n all (When equipped with wheel 40-84B); A Main J-3 s/n all (When equipped with wheel 40-84B); A Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84); A Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); A Main J3C-40 s/n all (When equipped with wheel 40-84); A Main J3C-40 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);	A		Aux	
Aux PA-60-602P (Ted Smith Aerostar 602P) s/n all (When equipped with wheel 40-76F); A MC153-01500 153-01500, 153-15, 755-930 Main J-3 s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);				
equipped with wheel 40-76F); A MC153-01500 153-01500, 153-15, Main J-3 s/n all (When equipped with wheel 40-84); A Main J-3 s/n all (When equipped with wheel 40-84B); A Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84A); A Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); A Main J3C-40 s/n all (When equipped with wheel 40-84); A Main J3C-40 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B);	A		Διιγ	
MC153-01500 153-01500, 153-15, Main Main J-3 s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);			/ lux	
Main J-3 s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50S s/n all (When equipped with wheel 40-84B);				equipped with wheel 40-70F),
Main J-3 s/n all (When equipped with wheel 40-84B); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);	MC153-01500	·	Main	J-3 s/n all (When equipped with wheel 40-84);
Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84); Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);	A		Main	J-3 s/n all (When equipped with wheel 40-84B);
Main J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B); Main J3C-40 s/n all (When equipped with wheel 40-84); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84B);	A			J3 (Converted TG-8 Glider) s/n all (When equipped with
wheel 40-84B); A Main J3C-40 s/n all (When equipped with wheel 40-84); A Main J3C-40 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B); A Main J3C-50 s/n all (When equipped with wheel 40-84B);	A		Main	
Main J3C-40 s/n all (When equipped with wheel 40-84); Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50S s/n all (When equipped with wheel 40-84);			Mani	, , , , , , , , , , , , , , , , , , , ,
Main J3C-40 s/n all (When equipped with wheel 40-84B); Main J3C-50 s/n all (When equipped with wheel 40-84); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50S s/n all (When equipped with wheel 40-84);	A		Main	
Main J3C-50 s/n all (When equipped with wheel 40-84); Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50S s/n all (When equipped with wheel 40-84);				, , , , , , , , , , , , , , , , , , , ,
Main J3C-50 s/n all (When equipped with wheel 40-84B); Main J3C-50S s/n all (When equipped with wheel 40-84);				
Main J3C-50S s/n all (When equipped with wheel 40-84);				, , , , , , , , , , , , , , , , , , , ,
rivain J3C-50S s/n all (When equipped with wheel 40-84B);				
	^		iviain	J3C-50S s/n all (When equipped with wheel 40-84B);



ev Part Number MC153-01500	Replaces 153-01500, 153-15,	<u>Location</u> Main	Model and Serial Number Range J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
	755-930		(When equipped with wheel 40-84);
A	700 000	Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
		Wilding	(When equipped with wheel 40-84B);
A		Main	J3C-65S s/n all (When equipped with wheel 40-84);
A		Main	J3C-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3F-50 s/n all (When equipped with wheel 40-84);
A		Main	J3F-50 s/n all (When equipped with wheel 40-84B);
1		Main	J3F-50S s/n all (When equipped with wheel 40-84);
1		Main	J3F-50S s/n all (When equipped with wheel 40-84B);
1		Main	J3F-60 s/n all (When equipped with wheel 40-84);
		Main	J3F-60 s/n all (When equipped with wheel 40-84B);
		Main	J3F-60S s/n all (When equipped with wheel 40-84);
		Main	J3F-60S s/n all (When equipped with wheel 40-84B);
		Main	
		iviaii i	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84):
		Main	//
		iviaii i	J3F-65 (Army L-4D) s/n all (When equipped with wheel
		Main	40-84B);
			J3F-65S s/n all (When equipped with wheel 40-84);
		Main	J3F-65S s/n all (When equipped with wheel 40-84B);
		Main	J3L s/n all (When equipped with wheel 40-84);
		Main	J3L s/n all (When equipped with wheel 40-84B);
		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84);
1		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84B);
L		Main	J3L-65S s/n all (When equipped with wheel 40-84);
		Main	J3L-65S s/n all (When equipped with wheel 40-84B);
		Main	J3L-S s/n all (When equipped with wheel 40-84);
		Main	J3L-S s/n all (When equipped with wheel 40-84B);
		Main	J3P s/n all (When equipped with wheel 40-84);
		Main	J3P s/n all (When equipped with wheel 40-84B);
		Main	PA-11 s/n all (When equipped with wheel 40-84);
		Main	PA-11 s/n all (When equipped with wheel 40-84B);
		Main	PA-11S s/n all (When equipped with wheel 40-84);
		Main	PA-11S s/n all (When equipped with wheel 40-84B);
		Main	PA-18 s/n all (When equipped with wheel 40-84);
		Main	PA-18 s/n all (When equipped with wheel 40-84B);
		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84);
		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84B);
		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-84);
		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
		Maii	wheel 40-84B);
			WIICCI 40-04D),



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC153-01500	153-01500, 153-15,	Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
	755-930		wheel 40-84);
Α		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84B);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84B);
A .		Main	PA-18A s/n all (When equipped with wheel 40-84);
A .		Main	PA-18A s/n all (When equipped with wheel 40-84B);
A .		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);
Α		Main	PA-18A "135" s/n all (When equipped with wheel
			40-84B);
A .		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "150" s/n all (When equipped with wheel
			40-84B);
Α .		Main	PA-20 s/n all (When equipped with wheel 40-84);
Α		Main	PA-20 s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
Α		Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
Α		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
Α		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
Α		Main	PA-22 s/n all (When equipped with wheel 40-84);
Α		Main	PA-22 s/n all (When equipped with wheel 40-84B);
Α		Main	PA-22-108 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
Α		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A		Main Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84B); PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
		IVIAIII	with wheel 40-84);
A		Main	<i>,</i> ,
		IVIAIII	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped with wheel 40-84B);
A		Main	PA-24-400* s/n 24-130 thru 26-148 (When equipped with
		Mani	wheel 40-90);
A		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
		Mani	equipped with wheel 40-90A);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
		Mani	with wheel 40-90A);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
		Mani	equipped with wheel 40-84);
			equipped with wheel to ot),



Rev Part Number	<u>Replaces</u>	<u>Location</u>	Model and Serial Number Range
^A MC153-01500	153-01500, 153-15,	Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
	755-930		equipped with wheel 40-84B);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84B);
A		Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
			wheel 40-90);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-90);
Α		Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-120C);
A		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-90A);
A		Main	PA-32-301FT s/n all (When equipped with wheel
			40-120C);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-120C);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-301XTC s/n all (When equipped with wheel
			40-120C);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-90A);
A		Main	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-90A);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120C);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-90A);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
		Widili	01 200 on an (1111011 equipped with wheel 40-1200),



_	D (N)			
	Part Number	Replaces	<u>Location</u> Main	Model and Serial Number Range PA-34-200 s/n all (When equipped with wheel 40-90);
	MC153-01500	153-01500, 153-15,	IVIAIII	PA-34-200 S/II all (When equipped with wheel 40-90),
A		755-930	Main	DA 24 200 g/n all (Mhan aguinned with wheel 40 00A):
A			Main	PA-34-200 s/n all (When equipped with wheel 40-90A);
A			Main	PA-34-200T s/n all (When equipped with wheel 40-120C);
A				PA-34-200T s/n all (When equipped with wheel 40-90A);
			Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
A			Main	equipped with wheel 40-120C);
			IVIAIII	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
A			Main	equipped with wheel 40-90A);
			IVIAIII	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
A			Main	with wheel 40-120C);
			IVIAIII	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
A			Main	with wheel 40-90A);
			IVIAIII	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
A			Main	with wheel 40-120C);
			IVIAIII	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
A			Main	with wheel 40-90A);
			IVIAIII	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
A			Main	with wheel 40-120C); PA-34-220T* s/n 3449001 thru 3449999 (When equipped
			IVIAIII	with wheel 40-120C);
A			Main	PA-39 s/n all (When equipped with wheel 40-90);
A			Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			IVICIII	equipped with wheel 40-120);
A			Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			IVICIII	equipped with wheel 40-120C);
A			Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			IVIAIII	equipped with wheel 40-90A);
A			Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			Main	with wheel 40-120);
A			Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			Main	with wheel 40-120C);
A			Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			Main	with wheel 40-90A);
A			Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			Man	with wheel 40-120);
A			Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			· · · · · · · · · · · · · · · · · · ·	with wheel 40-120C);
A			Main	PA-44-180T s/n all (When equipped with wheel 40-120);
A			Main	PA-44-180T s/n all (When equipped with wheel 40-120C);
А			Main	PA-44-180T s/n all (When equipped with wheel 40-90A);
А			Main	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
				equipped with wheel 40-120C);
A			Main	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
				with wheel 40-120C);
				Wilder 10 1200j,
1				



Part Number MC153-01500	Replaces	<u>Location</u>	Model and Serial Number Range
	153-01500, 153-15,	Main	PA-46-350P (w/ G1000) s/n all (When equipped with
A	755-930		wheel 40-120C);
	100 000	Main	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-120C);
A		Main	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
			(When equipped with wheel 40-120C);
A		Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
		Main	wheel 40-142):
A		Main	PA-46-500TP (w/o G1000) s/n all (When equipped with
		Mani	wheel 40-142):
A		Main	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-60-600 s/n all (When equipped with wheel 40-124);
A		Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
		-	equipped with wheel 40-124);
A		Main	PA-60-601 s/n all (When equipped with wheel 40-124);
A		Main	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
			equipped with wheel 40-124);
A		Main	PA-60-601P s/n all (When equipped with wheel 40-124);
A		Main	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
			equipped with wheel 40-124);
A		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
A		Main	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-124);
	153-01600, 153-16,	Main	J-3 s/n all (When equipped with wheel 40-84B);
^A MC153-01600			
A MC153-01600	755-963	Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B);
A		Main Main	
a a			wheel 40-84B);
a a		Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B);
A A A		Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B);
a a a		Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B);
a a a		Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
		Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B);
		Main Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B); J3C-65S s/n all (When equipped with wheel 40-84B);
A A A A A		Main Main Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B); J3C-65S s/n all (When equipped with wheel 40-84B); J3F-50 s/n all (When equipped with wheel 40-84B);
		Main Main Main Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B); J3C-65S s/n all (When equipped with wheel 40-84B); J3F-50 s/n all (When equipped with wheel 40-84B);
A A A A A A A A A A A A A A A A A A A		Main Main Main Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B); J3C-65S s/n all (When equipped with wheel 40-84B); J3F-50 s/n all (When equipped with wheel 40-84B); J3F-50S s/n all (When equipped with wheel 40-84B); J3F-60 s/n all (When equipped with wheel 40-84B);
A A A A A A		Main Main Main Main Main Main Main Main	wheel 40-84B); J3C-40 s/n all (When equipped with wheel 40-84B); J3C-50 s/n all (When equipped with wheel 40-84B); J3C-50S s/n all (When equipped with wheel 40-84B); J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84B); J3C-65S s/n all (When equipped with wheel 40-84B); J3F-50 s/n all (When equipped with wheel 40-84B); J3F-60 s/n all (When equipped with wheel 40-84B); J3F-60S s/n all (When equipped with wheel 40-84B); J3F-60S s/n all (When equipped with wheel 40-84B);



ev Part Number MC153-01600	Replaces 153-01600, 153-16,	<u>Location</u> Main	Model and Serial Number Range J3L-65 (Army L-4C) s/n all (When equipped with wheel
1110 100 0 1000	755-963	· · · · · · · · · · · · · · · · · · ·	40-84B);
1	733-903	Main	J3L-65S s/n all (When equipped with wheel 40-84B);
1		Main	J3L-S s/n all (When equipped with wheel 40-84B);
A.		Main	J3P s/n all (When equipped with wheel 40-84B);
		Main	PA-11 s/n all (When equipped with wheel 40-84B);
` A		Main	PA-11S s/n all (When equipped with wheel 40-84B);
		Main	PA-18 s/n all (When equipped with wheel 40-84B);
1		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84B);
		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-84B);
		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84B);
		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84B);
		Main	PA-18A s/n all (When equipped with wheel 40-84B);
		Main	PA-18A "135" s/n all (When equipped with wheel
			40-84B);
		Main	PA-18A "150" s/n all (When equipped with wheel
			40-84B);
		Main	PA-20 s/n all (When equipped with wheel 40-84B);
		Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
		Main	PA-22 s/n all (When equipped with wheel 40-84B);
		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
		Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
		Main	PA-22-160 s/n all (When equipped with wheel 40-84B);
		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
		IVICIII	`
		Main	with wheel 40-84B);
		iviaiii	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
		Main	equipped with wheel 40-84B);
		IVIAIII	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
		Main	equipped with wheel 40-84B);
		Main	PA-31 s/n all (When equipped with wheel 40-162);
		Main	PA-31* s/n 31-5 thru 31-7300962 (When equipped with
		NA . 1	wheel 40-102);
		Main	PA-31* s/n 31-5 thru 31-7712103 (When equipped with
			wheel 40-130);
		Main	PA-31* s/n 31-7300963 thru 31-8312019 (When equipped
			with wheel 40-102A);
		Main	PA-31* s/n 31-7812001 thru 31-8312019 (When equipped
			with wheel 40-130);
		Main	PA-31-300 s/n all (When equipped with wheel 40-162);



153-01600, 153-16,	<u>Location</u> Main	Model and Serial Number Range PA-31-300* s/n 31-5 thru 31-7300962 (When equipped
	Main	· · · · ·
755-963	Main	with wheel 40-102);
	iviaiii	PA-31-300* s/n 31-7300963 thru 31-8312019 (When
	Main	equipped with wheel 40-102A);
	iviain	PA-31-300* s/n 31-7812001 thru 31-8312019 (When
	B.4. *	equipped with wheel 40-130);
	Main	PA-31-325* s/n 31-7400990 thru 31-7712103 (When
		equipped with wheel 40-130);
	Main	PA-31-325* s/n 31-7400990 thru 31-8112037 (When
		equipped with wheel 40-102A);
		PA-31-325 s/n all (When equipped with wheel 40-162);
	Main	PA-31-325* s/n 31-7812001 thru 31-8312019 (When
		equipped with wheel 40-130);
	Main	PA-31-350* s/n 31-5001 thru 31-7652075 (When
		equipped with wheel 40-102A);
	Main	PA-31-350* s/n 31-5001 thru 31-7652075 (When
		equipped with wheel 40-130);
	Main	PA-31-350 s/n all (When equipped with wheel 40-162);
	Main	PA-31-350* s/n 31-7652076 thru 31-8553002 (When
		equipped with wheel 40-130);
	Main	PA-31-350 (T1020) s/n all (When equipped with wheel
	-	40-130);
	Main	PA-31P-350 s/n all (When equipped with wheel 40-130);
153-01900, 153-19,	Main	PA-31-350* s/n 31-5001 thru 31-8052030 (When
763-703		equipped with wheel 40-141);
	Main	PA-31-350* s/n 31-8052031 thru 31-8553002 (When
		equipped with wheel 40-141);
	Main	PA-31-350 (T1020) s/n all (When equipped with wheel
		40-141);
	Main	PA-31P s/n all (When equipped with wheel 40-141);
	Main	PA-31P-350 s/n all (When equipped with wheel 40-141);
	Main	PA-31T s/n all (When equipped with wheel 40-106);
		PA-31T1 s/n all (When equipped with wheel 40-106A);
		PA-31T1* s/n 31T-7804001 thru 31T-8104101 (When
	····	equipped with wheel 40-106);
	Main	PA-31T1* s/n 31T-8304001 thru 31T-1104017 (When
	Mani	•
	Main	equipped with wheel 40-106); PA-31T2 s/n all (When equipped with wheel 40-167);
	ivialii	PA-31T3 (T1040) s/n all (When equipped with wheel
	NA = i	40-167);
	Main	PA-31T3 (T1040) s/n all (When equipped with wheel
		40-167A);
		PA-42 s/n all (When equipped with wheel 40-166);
	Main	PA-42-720* s/n 42-5501003 thru 42-5501039 (When
		equipped with wheel 40-166);
		equipped with wheel 40-100),
		equipped with wheel 40-100),
		equipped with wheel 40-100),
	153-01900, 153-19,	Main Main Main Main Main Main Main Main



Part Number MC153-01900	Replaces 153-01900, 153-19,	<u>Location</u> Main	Model and Serial Number Range PA-42-720* s/n 42-8301001 thru 42-8301002 (When
763-703			equipped with wheel 40-166);
	7.00 7.00	Main	PA-42-720* s/n 42-5501040 thru 42-5501060 (When
			equipped with wheel 40-166);
		Main	PA-42-720R s/n all (When equipped with wheel 40-166);
			.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
MC153-30014	153-30014, 762-558,	Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
	A-30014		equipped with wheel D-30625);
		Aux	PA-28-150 s/n all (When equipped with wheel D-30625);
		Aux	PA-28-160 s/n all (When equipped with wheel D-30625);
		Aux	PA-28-180 s/n all (When equipped with wheel D-30625);
		Aux	PA-28-181* s/n 28-7690001 thru 28-7890419 (When
			equipped with wheel D-30625);
		Aux	PA-28-181* s/n 28-7890420 thru 28-8690062 (When
			equipped with wheel D-30665);
		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel D-30665);
		Aux	PA-28-235* s/n 28-10003 thru 28-7710089 (When
			equipped with wheel D-30625);
		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel D-30665);
		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel D-30665);
		Aux	PA-32-260* s/n 32-1 thru 32-7800006 (When equipped
			with wheel D-30625);
		Aux	PA-32-260* s/n 32-7800007 thru 32-7800008 (When
			equipped with wheel D-30665);
		Aux	PA-32-300* s/n 32-40000 thru 32-7840101 (When
			equipped with wheel D-30625);
		Aux	PA-32-300* s/n 32-7540102 thru 32-7940290 (When
			equipped with wheel D-30665);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel D-30665);
		Aux	PA-32-301FT s/n all (When equipped with wheel
			D-30665);
		Aux	PA-32-301T s/n all (When equipped with wheel D-30665)
		Aux	PA-32-301XTC s/n all (When equipped with wheel
			D-30665);
		Aux	PA-34-200 s/n all (When equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7570001 thru 34-7870190 (When
			equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7870191 thru 34-8170092 (When
			equipped with wheel D-30665);
		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel D-30665);



ev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC153-30014	153-30014, 762-558,	Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
A-3	A-30014	Λ	with wheel D-30665);
		Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel D-30665);
MC153-30015	153-30015, 762-559,	Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
	A-30015		equipped with wheel D-30625);
ı		Aux	PA-28-150 s/n all (When equipped with wheel D-30625);
L		Aux	PA-28-160 s/n all (When equipped with wheel D-30625);
L		Aux	PA-28-180 s/n all (When equipped with wheel D-30625);
		Aux	PA-28-181* s/n 28-7690001 thru 28-7890419 (When
			equipped with wheel D-30625);
		Aux	PA-28-181* s/n 28-7890420 thru 28-8690062 (When
			equipped with wheel D-30665);
		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel D-30665);
		Aux	PA-28-235* s/n 28-10003 thru 28-7710089 (When
			equipped with wheel D-30625);
		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel D-30665);
		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel D-30665);
		Aux	PA-32-260* s/n 32-1 thru 32-7800006 (When equipped
			with wheel D-30625);
		Aux	PA-32-260* s/n 32-7800007 thru 32-7800008 (When
			equipped with wheel D-30665);
		Aux	PA-32-300* s/n 32-40000 thru 32-7840101 (When
			equipped with wheel D-30625);
		Aux	PA-32-300* s/n 32-7540102 thru 32-7940290 (When
			equipped with wheel D-30665);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel D-30665);
		Aux	PA-32-301FT s/n all (When equipped with wheel
			D-30665);
		Aux	PA-32-301T s/n all (When equipped with wheel D-30665):
		Aux	PA-32-301XTC s/n all (When equipped with wheel
			D-30665);
		Aux	PA-34-200 s/n all (When equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7570001 thru 34-7870190 (When
		, tan	equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7870191 thru 34-8170092 (When
		Aux	equipped with wheel D-30665);
		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
		Aux	•
		Aux	equipped with wheel D-30665);
A		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped with wheel D-30665);



Rev Part Number MC153-30015	Replaces 153-30015, 762-559, A-30015	<u>Location</u> Aux	Model and Serial Number Range PA-34-220T* s/n 3448001 thru 3448079 (When equipped with wheel D-30665);
^A MC154-00200	154-00200, 754-849	Main	J-3 s/n all (When equipped with wheel 40-60);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-60);
A		Main	J3C-40 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50S s/n all (When equipped with wheel 40-60);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-60);
A		Main	J3C-65S s/n all (When equipped with wheel 40-60);
A		Main	J3F-50 s/n all (When equipped with wheel 40-60);
A		Main	J3F-50S s/n all (When equipped with wheel 40-60);
A		Main	J3F-60 s/n all (When equipped with wheel 40-60);
A		Main	J3F-60S s/n all (When equipped with wheel 40-60);
A		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel
			40-60);
A		Main	J3F-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L s/n all (When equipped with wheel 40-60);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-60):
A		Main	J3L-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L-S s/n all (When equipped with wheel 40-60);
A		Main	J3P s/n all (When equipped with wheel 40-60);
A		Main	J4 s/n all (When equipped with wheel 40-60);
A		Main	J4A s/n all (When equipped with wheel 40-60);
A		Main	J4A-S s/n all (When equipped with wheel 40-60);
A		Main	J4B s/n all (When equipped with wheel 40-60);
A		Main	J4E (Army L-4E) s/n all (When equipped with wheel 40-60);
A		Main	J4F s/n all (When equipped with wheel 40-60);
A		Main	AE-1 s/n all (When equipped with wheel 40-60);
A		Main	HE-1 s/n all (When equipped with wheel 40-60);
A		Main	J5A (Army L-4F) s/n all (When equipped with wheel 40-60);
A		Main	J5A-80 s/n all (When equipped with wheel 40-60);
A		Main	J5B (Army L-4G) s/n all (When equipped with wheel 40-60):
A		Main	J5C s/n all (When equipped with wheel 40-60);
A		Main	PA-11 s/n all (When equipped with wheel 40-60);
A		Main	PA-11S s/n all (When equipped with wheel 40-60);
A		Main	PA-12 s/n all (When equipped with wheel 40-60);
A		Main	PA-12S s/n all (When equipped with wheel 40-60);
A		Main	PA-14 s/n all (When equipped with wheel 40-60);
A		Main	PA-15 s/n all (When equipped with wheel 40-60);



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC154-00200	154-00200, 754-849	Main	PA-16 s/n all (When equipped with wheel 40-60);
A		Main	PA-16S s/n all (When equipped with wheel 40-60);
A		Main	PA-17 s/n all (When equipped with wheel 40-60);
A		Main	PA-18 s/n all (When equipped with wheel 40-60);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel 40-60);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with wheel 40-60);
A		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with wheel 40-60);
A		Main	PA-18 "150"* s/n 18-3781 thru 18-8309025 (When
A		Main	equipped with wheel 40-60); PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
A		Main	with wheel 40-60);
Α		Main	PA-18A s/n all (When equipped with wheel 40-60);
Α		Main Main	PA-18A "135" s/n all (When equipped with wheel 40-60);
••		IVIAIII	PA-18A "150"* s/n 18-3781 thru 18-8309025 (When
A		Main	equipped with wheel 40-60); PA-20 s/n all (When equipped with wheel 40-60);
A		Main	PA-20 s/n all (When equipped with wheel 40-60);
A		Main	PA-20 '113 s/n all (When equipped with wheel 40-60);
		IVIAIII	1 A-20 133 3/11 all (When equipped with wheel 40-00),
^A MC154-00300	154-00300, 154-3, 3021, 751-772	Main	J-3 s/n all (When equipped with wheel 40-84);
Α		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84);
A		Main	J3C-40 s/n all (When equipped with wheel 40-84);
A		Main	J3C-50 s/n all (When equipped with wheel 40-84);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all (When equipped with wheel 40-84);
A		Main	J3C-65S s/n all (When equipped with wheel 40-84);
A		Main	J3F-50 s/n all (When equipped with wheel 40-84);
Α		Main	J3F-50S s/n all (When equipped with wheel 40-84);
A		Main	J3F-60 s/n all (When equipped with wheel 40-84);
A		Main	J3F-60S s/n all (When equipped with wheel 40-84);
A		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84);
Α		Main	J3F-65S s/n all (When equipped with wheel 40-84);
A		Main	J3L s/n all (When equipped with wheel 40-84);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84):
A		Main	J3L-65S s/n all (When equipped with wheel 40-84);
Α		Main	J3L-S s/n all (When equipped with wheel 40-84);
A		Main	J3P s/n all (When equipped with wheel 40-84);
A		Main	PA-11 s/n all (When equipped with wheel 40-84);



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC154-00300	154-00300, 154-3,	Main	PA-11S s/n all (When equipped with wheel 40-84);
A	3021, 751-772	Main	PA-18 s/n all (When equipped with wheel 40-84);
A		Main	PA-18 3/11 all (When equipped with wheel PA-18 "105" (Special) s/n all (When equipped with wheel
		IVICIII	40-84);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
		Wall	wheel 40-84);
A		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
			wheel 40-84);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
_			equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
A			with wheel 40-84);
Α		Main	PA-18A s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-22 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A		Main	PA-23 s/n all (When equipped with wheel 3080A (40-3));
•		Main	PA-23-160 s/n all (When equipped with wheel 3080A
A		Main	(40-3));
		Main	PA-23-235 s/n all (When equipped with wheel 3080B
A		Main	(40-4)); PA-23-235 s/n all (When equipped with wheel 40-131);
A		Main	
		iviaiii	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-3737 (When equipped with wheel 3080B (40-4));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-7554149
		iviaiii	(When equipped with wheel 40-131);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-3738 thru 27-7554137
		Mani	(When equipped with wheel 3080D (40-116));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554141 thru
		Wall	27-7554149 (When equipped with wheel 3080D (40-116));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554150 thru
		mani	27-8154030 (When equipped with wheel 40-131);
A		Main	PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped
			with wheel 3080B (40-4));
A		Main	PA-E23-250* s/n 27-2505 thru 27-7554149 (When
			equipped with wheel 40-131);
Α		Main	PA-E23-250* s/n 27-3738 thru 27-7554137 (When
		-	equipped with wheel 3080D (40-116));
			- 1 whi - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
A MC154-00300	154-00300, 154-3,	Main	PA-E23-250* s/n 27-7554141 thru 27-7554149 (When
	3021, 751-772		equipped with wheel 3080D (40-116));
A	, .	Main	PA-E23-250* s/n 27-7554150 thru 27-7554168 (When
			equipped with wheel 40-131);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
			with wheel 40-84);
A		Main	PA-24-400* s/n 24-130 thru 26-148 (When equipped with
			wheel 40-90);
A		Main	PA-25-235* s/n 25-4172 thru 25-8156024 (When
			equipped with wheel 40-84A);
A		Main	PA-25-260* s/n 25-4415 thru 25-8156024 (When
			equipped with wheel 40-84A);
A		Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
			equipped with wheel 40-86);
A		Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
			equipped with wheel 40-86B);
A		Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86);
A		Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86B);
A		Main	PA-28-151 s/n all (When equipped with wheel 40-86B);
A		Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86);
A		Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
			with wheel 40-86B);
A		Main	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			with wheel 40-86B);
A		Main	PA-28-161* s/n 2841001 thru 2841365 (When equipped
_			with wheel 40-86B);
A		Main	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-86B);
A		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86);
A		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
A		N.4	equipped with wheel 40-86B);
A		Main	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
A		N.4 - :	equipped with wheel 40-86B);
, î		Main	PA-28-181* s/n 2890001 thru 2890231 (When equipped
A		Main	with wheel 40-86B);
		Main	PA-28-181* s/n 2843001 thru 2843999 (When equipped
A		Main	with wheel 40-86B); PA-28-201T s/n all (When equipped with wheel 40-86B);
A		Main	
		IVIQIII	PA-28-235* s/n 28-10487 thru 28-7710089 (When
A		Main	equipped with wheel 40-86); PA-28-235* s/n 28-10487 thru 28-7710089 (When
		iviaiii	· ·
			equipped with wheel 40-86B);



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^ MC154-00300	154-00300, 154-3,	Main	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
	3021, 751-772		equipped with wheel 40-86B);
A		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
			equipped with wheel 40-90A);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-86B);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-90A);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
			equipped with wheel 40-84);
A		Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
			equipped with wheel 40-86);
A		Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
			equipped with wheel 40-86B);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84);
A		Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
		Wani	equipped with wheel 40-86);
A		Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
		IVIAIII	•
A		Main	equipped with wheel 40-86B);
		iviaiii	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
A		Main	equipped with wheel 40-86B);
		Main	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
A		N.A	with wheel 40-86B);
A .		Main	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
			with wheel 40-86B);
A		Main	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel 40-86B);
A		Main	PA-28R-201T* s/n 2803001 thru 2803012 (When
			equipped with wheel 40-86B);
A		Main	PA-28RT-201 s/n all (When equipped with wheel
			40-86B);
A		Main	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-86B);
A		Main	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-86B);
A		Main	PA-30* s/n 30-2 thru 30-845 (When equipped with wheel
			40-34);
A		Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
			wheel 40-90);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-90);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90A);
		WiGht	17. 02 000 off all (triton equipped with wheel 40 00A),



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
A MC154-00300	154-00300, 154-3,	Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
	3021, 751-772		equipped with wheel 40-120C);
A	0021, 701 772	Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
		Wall	equipped with wheel 40-90A);
A		Main	PA-32-301FT s/n all (When equipped with wheel
		Mani	40-120C);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-120C);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-301XTC s/n all (When equipped with wheel
		Mani	40-120C);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
		IVICIII	with wheel 40-90A);
A		Main	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
		IVICIII	with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3229001 thru 3229003 (When
		IVICIII	`
A		Main	equipped with wheel 40-120C); PA-32R-301T* s/n 3257001 thru 3257999 (When
		IVIAIII	equipped with wheel 40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32RT-300 s/n all (When equipped with wheel
		IVIAIII	40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel
		IVIAIII	40-90A);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
		IVICIII	40-120);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
		IVICIII	40-120C);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
		IVICIII	40-90A);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-90);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-90A);
A		Main	PA-34-200T s/n all (When equipped with wheel 40-120C);
A		Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
A		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
		IVICIII	equipped with wheel 40-120C);
A		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
		IVICIII	equipped with wheel 40-90A);
A		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
		IVIAIII	with wheel 40-120C);
A		Main	<i>,</i> ·
		IVIAIII	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
A		Main	with wheel 40-90A);
		IVIAIII	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-120C);
İ			



ev Part Number MC154-00300	Replaces	<u>Location</u> Main	Model and Serial Number Range PA-34-220T* s/n 3448001 thru 3448079 (When equipped
IVIC 134-00300	154-00300, 154-3,	iviaiii	
	3021, 751-772	Main	with wheel 40-90A);
		Main	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
		N.4. *	with wheel 40-120C);
		Main	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
			with wheel 40-120C);
		Main	PA-39 s/n all (When equipped with wheel 40-90);
•		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-120);
1		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-120C);
		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-90A);
		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120);
		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120C);
		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-90A);
i.		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
		Mani	with wheel 40-120);
		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
		Mairi	` ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '
		Main	with wheel 40-120C);
			PA-44-180T s/n all (When equipped with wheel 40-120);
		Main	PA-44-180T s/n all (When equipped with wheel 40-120C);
		Main	PA-44-180T s/n all (When equipped with wheel 40-90A);
ı		Main	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-120C);
		Main	PA-46-310P* s/n 4608001 thru 4608140 (When equipped with wheel 40-120C);
1		Main	PA-46-350P (w/ G1000) s/n all (When equipped with
		Mani	wheel 40-120C);
		Main	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
		Mairi	,
		Main	(When equipped with wheel 40-120C); PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		IVIAIII	· · · · · · · · · · · · · · · · · · ·
		Main	(When equipped with wheel 40-120C);
•		Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
		N.4. *	wheel 40-142);
		Main	PA-46-500TP (w/o G1000) s/n all (When equipped with
			wheel 40-142);
		Main	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
		Main	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-120C);
MC154-00400	154-00400	Main	PA-22 s/n all (When equipped with wheel 3040 (40-6));
	101 00 100	WIGHT	. 7. LE offi dir (************************************

	McFarlane Wiation, Inc. 696 East 1700 Road Baldwin City, Kansas 66006									
Title:			ELIGI	BILITY:	WHEEL SI	EAL I	KIT PI	PER		
Size:	A	Scale:	NA	Drawn:	LLE		Sheet:	38	of	79
Drawin	g Numbe	er:		6560)				RE	B

Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
MC154-00400	154-00400	Aux	PA-22 s/n all (When equipped with wheel 38501 (40-8));
		Main	PA-22 s/n all (When equipped with wheel 40-28);
		Aux	PA-22-108 s/n all (When equipped with wheel 38501
			(40-8));
		Main	PA-22-108 s/n all (When equipped with wheel 40-28);
		Main	PA-22-135 s/n all (When equipped with wheel 40-28);
		Main	PA-22-150 s/n all (When equipped with wheel 40-28);
		Main	PA-22-160 s/n all (When equipped with wheel 40-28);
		Aux	PA-23 s/n all (When equipped with wheel 38501 (40-8));
		Aux	PA-23-160 s/n all (When equipped with wheel 38501
			(40-8));
		Aux	PA-23-235 s/n all (When equipped with wheel 38501
			(40-8));
		Aux	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-4822 (When
			equipped with wheel 38501 (40-8));
		Aux	PA-E23-250* s/n 27-2505 thru 27-4822 (When equipped
			with wheel 38501 (40-8));
		Main	PA-24* s/n 24-1 thru 24-3306 (When equipped with
			wheel 3070 (40-5));
		Aux	PA-24 s/n all (When equipped with wheel 38501 (40-8))
		Main	PA-24* s/n 24-3307 thru 24-3687 (When equipped with
			wheel 40-58);
		Main	PA-24-250* s/n 24-1 thru 24-3306 (When equipped with
			wheel 3070 (40-5));
		Aux	PA-24-250* s/n 24-1 thru 24-3306 (When equipped with
		7.67	wheel 38501 (40-8));
		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
		Main	with wheel 40-58);
		Aux	PA-24-260* s/n 24-4000 thru 24-5019 (When equipped
		Nux	with wheel 38501 (40-8));
		Aux	PA-24-260* s/n 24-5021 thru 24-5023 (When equipped
		Aux	with wheel 38501 (40-8));
		Ausz	· //·
		Aux	PA-24-400 s/n all (When equipped with wheel 38501
		Main	(40-8));
			PA-25 s/n all (When equipped with wheel 3070 (40-5));
		Main	PA-25-235* s/n 25-2000 thru 25-4171 (When equipped
		Main	with wheel 40-61);
		Main	PA-28-140* s/n 28-20002 thru 28-20520 (When equippe
		٨	with wheel 40-28);
		Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
			equipped with wheel 38501 (40-8));
		Main	PA-28-150* s/n 28-1 thru 28-1760 (When equipped with
			wheel 40-28);
		Aux	PA-28-150 s/n all (When equipped with wheel 38501
			(40-8));



Rev Part Number	Replaces	Location	Model and Serial Number Range
^A MC154-00400	154-00400	Main	PA-28-160* s/n 28-1 thru 28-1760 (When equipped with
			wheel 40-28);
A		Aux	PA-28-160 s/n all (When equipped with wheel 38501
			(40-8));
A		Main	PA-28-180* s/n 28-671 thru 28-1760 (When equipped
			with wheel 40-28);
A		Aux	PA-28-180* s/n 28-671 thru 28-7205243 (When equipped
			with wheel 38501 (40-8));
A		Main	PA-28-235* s/n 28-10003 thru 28-10486 (When equipped
			with wheel 40-58);
A		Aux	PA-28-235* s/n 28-10003 thru 28-7210019 (When
A		A	equipped with wheel 38501 (40-8));
		Aux	PA-30* s/n 30-2 thru 30-2000 (When equipped with
A		A	wheel 38501 (40-8));
		Aux	PA-32-260* s/n 32-1 thru 31-7200029 (When equipped
A		Aux	with wheel 38501 (40-8)); PA-32-300* s/n 32-40000 thru 32-7240100 (When
		Aux	equipped with wheel 38501 (40-8));
A		Aux	PA-34-200* s/n 34-7250001 thru 34-7250216 (When
		Aux	equipped with wheel 38501 (40-8));
A		Aux	PA-39* s/n 39-1 thru 39-148 (When equipped with wheel
		, ton	38501 (40-8));
			00001 (40 0)),
^A MC154-00500	154-00500	Aux	PA-22 s/n all (When equipped with wheel 38501 (40-8));
A		Aux	PA-22-108 s/n all (When equipped with wheel 38501
			(40-8));
A .		Aux	PA-23 s/n all (When equipped with wheel 38501 (40-8));
A		Aux	PA-23-160 s/n all (When equipped with wheel 38501
Δ.		A	(40-8));
A		Aux	PA-23-235 s/n all (When equipped with wheel 38501
A		A	(40-8));
		Aux	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-4822 (When
A		Aux	equipped with wheel 38501 (40-8));
		Aux	PA-E23-250* s/n 27-2505 thru 27-4822 (When equipped
A		Aux	with wheel 38501 (40-8)); PA-24 s/n all (When equipped with wheel 38501 (40-8));
A		Aux	PA-24-250* s/n 24-1 thru 24-3306 (When equipped with
		, was	wheel 38501 (40-8));
A		Aux	PA-24-260* s/n 24-4000 thru 24-5019 (When equipped
			with wheel 38501 (40-8));
A		Aux	PA-24-260* s/n 24-5021 thru 24-5023 (When equipped
			with wheel 38501 (40-8));
A		Aux	PA-24-400 s/n all (When equipped with wheel 38501
			(40-8));
A		Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
			equipped with wheel 38501 (40-8));



ev Part Number MC154-00500	<u>Replaces</u> 154-00500	<u>Location</u> Aux	Model and Serial Number Range PA-28-150 s/n all (When equipped with wheel 38501
			(40-8));
A		Aux	PA-28-160 s/n all (When equipped with wheel 38501
			(40-8));
		Aux	PA-28-180* s/n 28-671 thru 28-7205243 (When equipped
		Aux	
		Aux	with wheel 38501 (40-8));
		Aux	PA-28-235* s/n 28-10003 thru 28-7210019 (When
		A	equipped with wheel 38501 (40-8));
		Aux	PA-30* s/n 30-2 thru 30-2000 (When equipped with
			wheel 38501 (40-8));
		Aux	PA-32-260* s/n 32-1 thru 31-7200029 (When equipped
			with wheel 38501 (40-8));
		Aux	PA-32-300* s/n 32-40000 thru 32-7240100 (When
			equipped with wheel 38501 (40-8));
		Aux	PA-34-200* s/n 34-7250001 thru 34-7250216 (When
			equipped with wheel 38501 (40-8));
		Aux	PA-39* s/n 39-1 thru 39-148 (When equipped with wheel
			38501 (40-8));
MC154-00600	154-00600, 154-6,	Aux	PA-28-151 s/n all (When equipped with wheel 40-77);
	754-804, 754-856,		
	A-30047		
	71 000 17	Aux	PA-28-151 s/n all (When equipped with wheel 40-77B);
		Aux	PA-28-151 s/n all (When equipped with wheel D-30500);
		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
		Aux	, , , , , , , , , , , , , , , , , , , ,
		Aux	with wheel 40-77);
		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
		A	with wheel 40-77B);
		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
		_	with wheel D-30500);
		Aux	PA-28-161* s/n 2841001 thru 2841365 (When equipped
			with wheel 40-77B);
		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-77);
		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-77B);
		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel D-30500);
		Aux	PA-28-201T s/n all (When equipped with wheel 40-77);
		Aux	PA-28-201T s/n all (When equipped with wheel 40-77B);
		Aux	PA-28-201T s/n all (When equipped with wheel D-30500);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77A);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77B);
		Aux	PA-28R-180 s/n all (When equipped with wheel
		Aux	, , , , ,
			D-30500);



Part Number MC154-00600	Replaces 154-00600, 154-6,	<u>Location</u> Aux	Model and Serial Number Range PA-28R-200 s/n all (When equipped with wheel 40-77);
	754-804, 754-856,		
	A-30047		
		Aux	PA-28R-200 s/n all (When equipped with wheel 40-77A);
		Aux	PA-28R-200 s/n all (When equipped with wheel 40-77B);
		Aux	PA-28R-200 s/n all (When equipped with wheel
			D-30500);
		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
			equipped with wheel 40-77);
		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Whe
			equipped with wheel 40-77B);
		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (Whe
			equipped with wheel D-30500);
		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equippe
			with wheel 40-77);
		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equippe
			with wheel 40-77B);
		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equippe
			with wheel D-30500);
		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equippe
			with wheel 40-77);
		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equippe
			with wheel 40-77B);
		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equippe
			with wheel D-30500);
		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel 40-77);
		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel 40-77B);
		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel D-30500);
		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
			equipped with wheel 40-77);
		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
			equipped with wheel 40-77B);
		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
			equipped with wheel D-30500);
		Aux	PA-28RT-201 s/n all (When equipped with wheel 40-77);
		Aux	PA-28RT-201 s/n all (When equipped with wheel
			40-77B);
		Aux	PA-28RT-201 s/n all (When equipped with wheel
			D-30500);
		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77);
		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77B);



Rev Part Number MC154-00600	Replaces 154-00600, 154-6,	<u>Location</u> Aux	Model and Serial Number Range PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
	754-804, 754-856, A-30047		(When equipped with wheel D-30500);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-77);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-77B);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel D-30500);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-77);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-77B);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel D-30500);
A		Aux	PA-32-301T s/n all (When equipped with wheel 40-77);
A		Aux	PA-32-301T s/n all (When equipped with wheel 40-77B);
A		Aux	PA-32-301T s/n all (When equipped with wheel D-30500);
Α		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77);
Α		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77B);
Α		Aux	PA-32R-300 s/n all (When equipped with wheel
			D-30500);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-77);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped with wheel 40-77B);
A		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped with wheel D-30500);
A		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped with wheel 40-77);
A		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-77B);
A		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel D-30500);
A		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-77);
A		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-77B);
A		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel D-30500);
A		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-77);
Α		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-77B);
A		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel D-30500);
			·



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC154-00600	154-00600, 154-6,	Aux	PA-32RT-300 s/n all (When equipped with wheel 40-77);
	754-804, 754-856,		
A	A-30047	A	DA CODT COO / WAN : I W I
*		Aux	PA-32RT-300 s/n all (When equipped with wheel
A		A	40-77B);
		Aux	PA-32RT-300 s/n all (When equipped with wheel
A		Aux	D-30500);
A		Aux	PA-32RT-300T s/n all (When equipped with wheel 40-77);
		Aux	PA-32RT-300T s/n all (When equipped with wheel 40-77B):
A		Aux	PA-32RT-300T s/n all (When equipped with wheel
		Aux	D-30500);
A		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
		Nux	equipped with wheel 40-77B);
A		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
		, tux	with wheel 40-77B);
A		Aux	PA-34-220T* s/n 3448001 thru 3448037 (When equipped
			with wheel 40-77B);
A		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77);
A		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77B);
A		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77C);
Α		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel D-30500);
A		Main	PA-38-112 s/n all (When equipped with wheel 40-78B);
A		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-77);
A		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-77B);
A		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel D-30500);
A		Aux	PA-44-180* s/n 4495001 thru 4495013 (When equipped
A		A	with wheel 40-77);
*		Aux	PA-44-180* s/n 4495001 thru 4495013 (When equipped
A		A	with wheel 40-77B);
•		Aux	PA-44-180* s/n 4495001 thru 4495013 (When equipped
A		Aux	with wheel D-30500);
		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
A		Aux	with wheel 40-77);
		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped with wheel 40-77B);
A		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
		7107	with wheel D-30500);
A		Aux	PA-44-180T s/n all (When equipped with wheel 40-77);



A MC154-00600	154-00600, 154-6, 754-804, 754-856,	Aux	PA-44-180T s/n all (When equipped with wheel 40-77B);
	A-30047		
A		Aux	PA-44-180T s/n all (When equipped with wheel D-30500);
		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-77);
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-77B);
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel D-30500);
A		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-77);
Α		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-77B);
Α		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel D-30500);
A		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-77);
Α		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
Α		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel D-30500);
Α		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
		_	(When equipped with wheel 40-77);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
À		•	(When equipped with wheel 40-77B);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
A		A	(When equipped with wheel D-30500);
n		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
A		Λιιν	(When equipped with wheel 40-77);
		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
A		Aux	(When equipped with wheel 40-77B); PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		Aux	(When equipped with wheel D-30500);
A		Aux	PA-46-500TP (w/ G1000) s/n all (When equipped with
		7 lux	wheel 40-77G):
A		Aux	PA-46-500TP (w/o G1000) s/n all (When equipped with
		7107	wheel 40-77G);
Α		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
		7 1671	wheel 40-77);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel D-30500);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-77);
			<i>"</i>



Rev Part Number MC154-00600	Replaces 154-00600, 154-6, 754-804, 754-856, A-30047	<u>Location</u> Aux	Model and Serial Number Range PA-46R-350T (w/o G1000) s/n all (When equipped with wheel 40-77B);
A	7.00047	Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with wheel D-30500);
A MC154-01300	154-01300, 154-13, 751-810	Main	J-3 s/n all (When equipped with wheel 40-84);
Α	701010	Main	J-3 s/n all (When equipped with wheel 40-84B);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with wheel 40-84B);
A		Main	J3C-40 s/n all (When equipped with wheel 40-84);
A		Main	J3C-40 s/n all (When equipped with wheel 40-84B);
A		Main	J3C-50 s/n all (When equipped with wheel 40-84);
A		Main	J3C-50 s/n all (When equipped with wheel 40-84B);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84);
A		Main	J3C-50S s/n all (When equipped with wheel 40-84B);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-84);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-84B);
A		Main	J3C-65S s/n all (When equipped with wheel 40-84);
A		Main	J3C-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3F-50 s/n all (When equipped with wheel 40-84);
A		Main	J3F-50 s/n all (When equipped with wheel 40-84B);
A		Main	J3F-50S s/n all (When equipped with wheel 40-84);
A		Main	J3F-50S s/n all (When equipped with wheel 40-84B);
A		Main	J3F-60 s/n all (When equipped with wheel 40-84);
A		Main	J3F-60 s/n all (When equipped with wheel 40-84B);
A		Main	J3F-60S s/n all (When equipped with wheel 40-84);
A		Main	J3F-60S s/n all (When equipped with wheel 40-84B);
A		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84);
A		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84B);
A		Main	J3F-65S s/n all (When equipped with wheel 40-84);
A		Main	J3F-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3L s/n all (When equipped with wheel 40-84);
A		Main	J3L s/n all (When equipped with wheel 40-84B);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel 40-84B);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84);



ev Part Number MC154-01300	Replaces 154-01300, 154-13,	<u>Location</u> Main	Model and Serial Number Range J3L-65S s/n all (When equipped with wheel 40-84B);
	751-810		TO COO OTT ATT (TITLEST ONLY POOR WITH WHOOL TO OTD),
A	751-610	Main	J3L-S s/n all (When equipped with wheel 40-84);
		Main	J3L-S s/n all (When equipped with wheel 40-84B);
		Main	J3P s/n all (When equipped with wheel 40-84);
		Main	J3P s/n all (When equipped with wheel 40-84B);
		Main	PA-11 s/n all (When equipped with wheel 40-84);
		Main	PA-11 s/n all (When equipped with wheel 40-84B);
		Main	PA-11S s/n all (When equipped with wheel 40-84);
		Main	PA-11S s/n all (When equipped with wheel 40-84B);
		Main	PA-18 s/n all (When equipped with wheel 40-84);
		Main	PA-18 s/n all (When equipped with wheel 40-84B);
		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
		IVICIII	40-84);
		Main	, ,
		Mail	PA-18 "105" (Special) s/n all (When equipped with wheel 40-84B);
		Main	· ·
		Mail	PA-18 "125" (Army L-21A) s/n all (When equipped with wheel 40-84):
		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
		IVIAIII	wheel 40-84B):
		Main	· · · · · · · · · · · · · · · · · · ·
		IVIAIII	PA-18 "135" (Army L-21B) s/n all (When equipped with
		Main	wheel 40-84); PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
		IVIAIII	•
		Main	equipped with wheel 40-84);
		iviaiii	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
		Main	equipped with wheel 40-84B); PA-18 "150"* s/n 1809001 thru 1809113 (When equipped)
		iviaiii	, , , , , , , , , , , , , , , , , , , ,
		Main	with wheel 40-84);
		iviaiii	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
		Main	with wheel 40-84B); PA-18A s/n all (When equipped with wheel 40-84);
		Main	PA-18A s/n all (When equipped with wheel 40-84B);
		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);
		Main	
		IVIAIII	PA-18A "135" s/n all (When equipped with wheel
		Main	40-84B);
		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
		iviaiii	PA-18A "150" s/n all (When equipped with wheel
		Main	40-84B); PA-20 s/n all (When equipped with wheel 40-84);
			PA-20 s/n all (When equipped with wheel 40-84B);
		Main	, , , , , , , , , , , , , , , , , , , ,
		Main Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
		Main Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
		Main	PA-22 s/n all (When equipped with wheel 40-84);
		Main	PA-22 s/n all (When equipped with wheel 40-84B);



Rev Part Number MC154-01300	Replaces 154-01300, 154-13,	<u>Location</u> Main	Model and Serial Number Range PA-22-108 s/n all (When equipped with wheel 40-84);
	751-810		
Α		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84B);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped with wheel 40-84);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped with wheel 40-84B);
A		Main	PA-24-400* s/n 24-130 thru 26-148 (When equipped with
		IVICIII	wheel 40-90);
A		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
		Wall	equipped with wheel 40-90A);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
		· · · · · · · · · · · · · · · · · · ·	with wheel 40-90A);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
		· · · · · · · · · · · · · · · · · · ·	equipped with wheel 40-84);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
			equipped with wheel 40-84B);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84B);
A		Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
			wheel 40-90);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-90);
Α		Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
Α		Main	PA-32-300 s/n all (When equipped with wheel 40-120);
Α		Main	PA-32-300 s/n all (When equipped with wheel 40-90);
Α		Main	PA-32-300 s/n all (When equipped with wheel 40-90A);
Α		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-120C);
Α		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-90A);
Α		Main	PA-32-301FT s/n all (When equipped with wheel
			40-120C);
Α		Main	PA-32-301T s/n all (When equipped with wheel 40-120C);
Α		Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
A		Main	PA-32-301XTC s/n all (When equipped with wheel 40-120C);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
i		Mail	171-0211-000 3/11 all (virion equipped with wheel 40-120),
i			



ev Part Number MC154-01300	<u>Replaces</u> 154-01300, 154-13,	<u>Location</u> Main	Model and Serial Number Range PA-32R-300 s/n all (When equipped with wheel 40-90A);
	751-810		
4		Main	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-90A);
A.		Main	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-120C);
		Main	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-120C);
		Main	PA-32RT-300 s/n all (When equipped with wheel 40-120);
<u>.</u>		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-120C);
1		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-90A);
.		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120);
		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120C):
		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-90A);
		Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
		Main	PA-34-200 s/n all (When equipped with wheel 40-90);
		Main	PA-34-200 s/n all (When equipped with wheel 40-90A);
		Main	PA-34-200T s/n all (When equipped with wheel 40-120C);
		Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-120C);
		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-90A);
		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-120C);
		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-90A);
		Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-120C);
		Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
		Main	with wheel 40-90A);
		Main	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
		Main	with wheel 40-120C);
		Main	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
		Maii	with wheel 40-120C);
		Main	PA-39 s/n all (When equipped with wheel 40-90);
		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
		iviaii i	equipped with wheel 40-120);
			equipped with wheel 40-120):



Rev Part Number	Replaces	Location	Model and Serial Number Range
^A MC154-01300	154-01300, 154-13,	Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
	751-810		equipped with wheel 40-120C);
A		Main	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-90A);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-120C);
A		Main	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-90A);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120);
A		Main	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-120C);
A .		Main	PA-44-180T s/n all (When equipped with wheel 40-120);
A .		Main	PA-44-180T s/n all (When equipped with wheel 40-120C);
A		Main	PA-44-180T s/n all (When equipped with wheel 40-90A);
A		Main	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-120C);
A		Main	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
A		B.4	with wheel 40-120C);
^		Main	PA-46-350P (w/ G1000) s/n all (When equipped with
Α		N 4 - :	wheel 40-120C);
^		Main	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
Α		N 4 - :	(When equipped with wheel 40-120C);
		Main	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
A		Main	(When equipped with wheel 40-120C);
		Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
A		Main	wheel 40-142);
		IVIAIII	PA-46-500TP (w/o G1000) s/n all (When equipped with
A		Main	wheel 40-142);
		IVIAIII	PA-46R-350T (w/ G1000) s/n all (When equipped with
Α		Main	wheel 40-120C); PA-46R-350T (w/o G1000) s/n all (When equipped with
		IVIAIII	wheel 40-120C);
A		Main	PA-60-600 s/n all (When equipped with wheel 40-124);
Α		Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
		IVIAIII	equipped with wheel 40-124);
A		Main	PA-60-601 s/n all (When equipped with wheel 40-124);
A		Main	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
		Wall	equipped with wheel 40-124);
A		Main	PA-60-601P s/n all (When equipped with wheel 40-124);
A		Main	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
		Mani	equipped with wheel 40-124);
A		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
			55 552. 5.11 dii (1111511 oquippod mai 1111661 16 124);
İ			



Rev Part Number MC154-01300	<u>Replaces</u> 154-01300, 154-13,	<u>Location</u> Main	Model and Serial Number Range PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
	751-810		equipped with wheel 40-124);
MC154-01400	154-01400, 154-14, 751-819	Aux	PA-22 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-23 s/n all (When equipped with wheel 40-76B);
A.		Aux	PA-23-160 s/n all (When equipped with wheel 40-76B);
A.		Aux	PA-23-250 (Navy UO-1)* s/n 27-4823 thru 27-8154030
			(When equipped with wheel 40-76B);
A.		Aux	PA-E23-250* s/n 27-4823 thru 27-7554168 (When
			equipped with wheel 40-76B);
L		Aux	PA-24-260* s/n 24-5020 thru 24-5034 (When equipped
			with wheel 40-76B);
4		Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
			equipped with wheel 40-76B);
A		Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
			equipped with wheel 40-76F);
ı		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76B);
ı		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76F);
ı		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-56B or 40-56);
		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-76F);
		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-56B or 40-56);
ı		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-76F);
		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-56B or 40-56);
		Aux	PA-28-235* s/n 28-7210020 thru 28-7710089 (When
			equipped with wheel 40-76B);
		Aux	PA-28-235* s/n 28-7210020 thru 28-7710089 (When
			equipped with wheel 40-76F);
<u>.</u>		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-56);
\		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-56);
\		Aux	PA-30* s/n 39-152 thru 30-2000 (When equipped with
			wheel 40-76B);
A		Aux	PA-31* s/n 31-5 thru 31-8112037 (When equipped with
			wheel 40-76B);
A.		Aux	PA-31* s/n 31-8112038 thru 31-8312019 (When equipped
			with wheel 40-140);
			··



ev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
MC154-01400	154-01400, 154-14,	Aux	PA-31-300* s/n 31-5 thru 31-8112037 (When equipped
	751-819		with wheel 40-76B);
		Aux	PA-31-300* s/n 31-8112038 thru 31-8312019 (When
			equipped with wheel 40-140);
		Aux	PA-31-325* s/n 31-7400990 thru 31-8112037 (When
			equipped with wheel 40-76B);
		Aux	PA-31-325* s/n 31-8112038 thru 31-8312019 (When
			equipped with wheel 40-140);
		Aux	PA-31-350* s/n 31-5001 thru 31-8152087 (When
			equipped with wheel 40-76B);
		Aux	PA-31-350* s/n 31-8152088 thru 31-8553002 (When
			equipped with wheel 40-140);
		Aux	PA-31-350 (T1020) s/n all (When equipped with wheel
		7 1371	40-140);
		Aux	PA-31P s/n all (When equipped with wheel 40-140);
		Aux	PA-31P s/n all (When equipped with wheel 40-76B);
		Aux	PA-31P-350 s/n all (When equipped with wheel 40-140);
		Aux	PA-31T s/n all (When equipped with wheel 40-140);
		Aux	PA-31T2 s/n all (When equipped with wheel 40-140);
		Aux	PA-31T3 (T1040) s/n all (When equipped with wheel
		Aux	, , , , , , , , , , , , , , , , , , , ,
		Aux	40-140);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
		A	equipped with wheel 40-56B or 40-56);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
		A	equipped with wheel 40-76B);
		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
			equipped with wheel 40-76F);
		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
		_	equipped with wheel 40-56B or 40-56);
		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-76B);
		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-76F);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-56B or 40-56);
		Aux	PA-32-301FT s/n all (When equipped with wheel 40-56B
			or 40-56);
		Aux	PA-32-301T s/n all (When equipped with wheel 40-56B o
			40-56);
		Aux	PA-32-301XTC s/n all (When equipped with wheel
			40-56B or 40-56);
		Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
			equipped with wheel 40-76B);
		Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
		- 19071	equipped with wheel 40-76F);
			equipped with wheel 40-701 j,



	rt Number	Replaces	Location	Model and Serial Number Range
^A MC	C154-01400	154-01400, 154-14,	Aux	PA-34-200T s/n all (When equipped with wheel 40-56B or
		751-819		40-56);
A			Aux	PA-34-200T s/n all (When equipped with wheel 40-76F);
Α			Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
				equipped with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
				with wheel 40-56B or 40-56);
Α			Aux	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
_				with wheel 40-56B or 40-56);
Α .			Main	PA-36-285 s/n all (When equipped with wheel 40-101);
Α .			Main	PA-36-300 s/n all (When equipped with wheel 40-101);
Α .			Main	PA-36-375 s/n all (When equipped with wheel 40-101);
Α .			Aux	PA-38-112 s/n all (When equipped with wheel 40-56);
Α .			Main	PA-38-112 s/n all (When equipped with wheel 40-59D);
Α .			Aux	PA-42 s/n all (When equipped with wheel 40-140);
Α .			Aux	PA-42-1000 s/n all (When equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-5501003 thru 42-5501039 (When
_			_	equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-8301001 thru 42-8301002 (When
_			_	equipped with wheel 40-140);
Α			Aux	PA-42-720* s/n 42-5501040 thru 42-5501060 (When
_			_	equipped with wheel 40-140);
Α .			Aux	PA-42-720R s/n all (When equipped with wheel 40-140);
Α .			Main	PA-60-600 s/n all (When equipped with wheel 40-124);
Α .			Aux	PA-60-600 s/n all (When equipped with wheel 40-76B);
A			Aux	PA-60-600 s/n all (When equipped with wheel 40-76F);
Α			Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
				equipped with wheel 40-124);
Α			Aux	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
Α				equipped with wheel 40-76B);
A			Aux	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
				equipped with wheel 40-76F);
A A			Main	PA-60-601 s/n all (When equipped with wheel 40-124);
A			Aux	PA-60-601 s/n all (When equipped with wheel 40-76B);
A			Aux	PA-60-601 s/n all (When equipped with wheel 40-76F);
^			Main	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
^			A	equipped with wheel 40-124);
Α			Aux	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
A			Δ	equipped with wheel 40-76B);
			Aux	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
^			N.4 - :	equipped with wheel 40-76F);
Α			Main	PA-60-601P s/n all (When equipped with wheel 40-124);



Part Number MC154-01400	Replaces 154-01400, 154-14,	<u>Location</u> Aux	Model and Serial Number Range PA-60-601P s/n all (When equipped with wheel 40-76B);
	751-819		
		Aux	PA-60-601P s/n all (When equipped with wheel 40-76F);
		Main	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
			equipped with wheel 40-124);
		Aux	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
			equipped with wheel 40-76B);
		Aux	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
			equipped with wheel 40-76F);
		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
		Aux	PA-60-602P s/n all (When equipped with wheel 40-76B);
		Aux	PA-60-602P s/n all (When equipped with wheel 40-76F);
		Main	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-124);
		Aux	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-76B);
		Aux	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-76F);
MC154-01600	154-01600, 154-16,	Main	J-3 s/n all (When equipped with wheel 40-84B);
	751-818		(
	70.0.0	Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-84B);
		Main	J3C-40 s/n all (When equipped with wheel 40-84B);
		Main	J3C-50 s/n all (When equipped with wheel 40-84B);
		Main	J3C-50S s/n all (When equipped with wheel 40-84B);
		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
		Main	(When equipped with wheel 40-84B);
		Main	J3C-65S s/n all (When equipped with wheel 40-84B);
		Main	J3F-50 s/n all (When equipped with wheel 40-84B);
		Main	J3F-50S s/n all (When equipped with wheel 40-84B);
		Main	J3F-60 s/n all (When equipped with wheel 40-84B);
		Main	J3F-60S s/n all (When equipped with wheel 40-84B);
		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel
		Mairi	40-84B);
		Main	J3F-65S s/n all (When equipped with wheel 40-84B);
		Main	J3L s/n all (When equipped with wheel 40-84B);
		Main	
		ivialii	J3L-65 (Army L-4C) s/n all (When equipped with wheel
			40-84B);
		Main	121 GEC a/n all (Mhan agriffered with wheel 40 04D)
		Main	J3L-65S s/n all (When equipped with wheel 40-84B);
		Main	J3L-S s/n all (When equipped with wheel 40-84B);
		Main Main	J3L-S s/n all (When equipped with wheel 40-84B); J3P s/n all (When equipped with wheel 40-84B);
		Main Main Main	J3L-S s/n all (When equipped with wheel 40-84B); J3P s/n all (When equipped with wheel 40-84B); PA-11 s/n all (When equipped with wheel 40-84B);
		Main Main	J3L-S s/n all (When equipped with wheel 40-84B); J3P s/n all (When equipped with wheel 40-84B);



Rev Part Number MC154-01600	Replaces 154-01600, 154-16,	<u>Location</u> Main	Model and Serial Number Range PA-18 "105" (Special) s/n all (When equipped with wheel
	751-818		40-84B);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-84B);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84B);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84B);
A		Main	PA-18A s/n all (When equipped with wheel 40-84B);
A		Main	PA-18A "135" s/n all (When equipped with wheel
			40-84B);
A		Main	PA-18A "150" s/n all (When equipped with wheel
			40-84B);
A		Main	PA-20 s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
A		Main	PA-22 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84B);
A		Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
		Wall	with wheel 40-84B);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
		Wall	equipped with wheel 40-84B);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
		Mairi	equipped with wheel 40-84B);
A		Main	PA-31 s/n all (When equipped with wheel 40-162);
A		Main	PA-31* s/n 31-5 thru 31-7300962 (When equipped with
		IVIAIII	`
A		Main	wheel 40-102); PA-31* s/n 31-5 thru 31-7712103 (When equipped with
		IVIAIII	`
A		Main	wheel 40-130);
		IVIAIII	PA-31* s/n 31-7300963 thru 31-8312019 (When equipped
A		Main	with wheel 40-102A);
		IVIAIII	PA-31* s/n 31-7812001 thru 31-8312019 (When equipped
A		Main	with wheel 40-130); PA-31-300 s/n all (When equipped with wheel 40-162);
A		Main	
		IVIAIII	PA-31-300* s/n 31-5 thru 31-7300962 (When equipped
A		Main	with wheel 40-102);
		Main	PA-31-300* s/n 31-7300963 thru 31-8312019 (When
A		Main	equipped with wheel 40-102A);
••		Main	PA-31-300* s/n 31-7812001 thru 31-8312019 (When
A		Main	equipped with wheel 40-130);
••		Main	PA-31-325* s/n 31-7400990 thru 31-7712103 (When
			equipped with wheel 40-130);



4 MC154-0			PA-31-325* s/n 31-7400990 thru 31-8112037 (When
A	751-818	-16, Main	equipped with wheel 40-102A);
	731-010	Main	PA-31-325 s/n all (When equipped with wheel 40-162);
A		Main	PA-31-325* s/n 31-7812001 thru 31-8312019 (When
		Walli	equipped with wheel 40-130);
A		Main	PA-31-350* s/n 31-5001 thru 31-7652075 (When
		Walli	equipped with wheel 40-102A);
A		Main	PA-31-350* s/n 31-5001 thru 31-7652075 (When
		Walli	equipped with wheel 40-130);
A		Main	PA-31-350 s/n all (When equipped with wheel 40-162);
A		Main	PA-31-350* s/n 31-7652076 thru 31-8553002 (When
		Wall	equipped with wheel 40-130);
A		Main	PA-31-350 (T1020) s/n all (When equipped with wheel
		IVICIII	40-130);
A		Main	PA-31P-350 s/n all (When equipped with wheel 40-130);
		IVIAIII	1 A-311 -330 3/11 all (When equipped with wheel 40-130),
A MC154-0	02600 154-02600, 154-	-26, Main	PA-31-350* s/n 31-5001 thru 31-8052030 (When
	762-325		equipped with wheel 40-141);
A		Main	PA-31-350* s/n 31-8052031 thru 31-8553002 (When
			equipped with wheel 40-141);
A		Main	PA-31-350 (T1020) s/n all (When equipped with wheel
			40-141);
A		Main	PA-31P s/n all (When equipped with wheel 40-141);
A		Main	PA-31P-350 s/n all (When equipped with wheel 40-141);
A		Main	PA-31T s/n all (When equipped with wheel 40-106);
A		Main	PA-31T1 s/n all (When equipped with wheel 40-106A);
A		Main	PA-31T1* s/n 31T-7804001 thru 31T-8104101 (When
			equipped with wheel 40-106);
A		Main	PA-31T1* s/n 31T-8304001 thru 31T-1104017 (When
			equipped with wheel 40-106);
A		Main	PA-31T2 s/n all (When equipped with wheel 40-167);
A		Main	PA-31T3 (T1040) s/n all (When equipped with wheel
			40-167);
A		Main	PA-31T3 (T1040) s/n all (When equipped with wheel
			40-167A);
A		Main	PA-42 s/n all (When equipped with wheel 40-166);
A		Main	PA-42-720* s/n 42-5501003 thru 42-5501039 (When
			equipped with wheel 40-166);
A		Main	PA-42-720* s/n 42-8301001 thru 42-8301002 (When
			equipped with wheel 40-166);
A		Main	PA-42-720* s/n 42-5501040 thru 42-5501060 (When
			equipped with wheel 40-166);
A		Main	PA-42-720R s/n all (When equipped with wheel 40-166);
			,
A MC154-0	02800 154-02800, 754-	-850 Main	J-3 s/n all (When equipped with wheel 40-60);
A		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-60);



<u>ev</u> <u>Part Number</u> A MC154-02800	Replaces 154-02800, 754-850	<u>Location</u> Main	Model and Serial Number Range J3C-40 s/n all (When equipped with wheel 40-60);
A	.5. 52550, 757 550	Main	J3C-50 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50S s/n all (When equipped with wheel 40-60);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
		Main	(When equipped with wheel 40-60);
A		Main	J3C-65S s/n all (When equipped with wheel 40-60);
A		Main	J3F-50 s/n all (When equipped with wheel 40-60);
1		Main	J3F-50S s/n all (When equipped with wheel 40-60);
		Main	J3F-60 s/n all (When equipped with wheel 40-60);
		Main	J3F-60S s/n all (When equipped with wheel 40-60);
		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel
		Main	40-60);
		Main	J3F-65S s/n all (When equipped with wheel 40-60);
		Main	J3L s/n all (When equipped with wheel 40-60);
		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel
		N 4 = :	40-60);
		Main	J3L-65S s/n all (When equipped with wheel 40-60);
		Main	J3L-S s/n all (When equipped with wheel 40-60);
		Main	J3P s/n all (When equipped with wheel 40-60);
		Main	J4 s/n all (When equipped with wheel 40-60);
		Main	J4A s/n all (When equipped with wheel 40-60);
		Main	J4A-S s/n all (When equipped with wheel 40-60);
		Main	J4B s/n all (When equipped with wheel 40-60);
		Main	J4E (Army L-4E) s/n all (When equipped with wheel 40-60);
		Main	J4F s/n all (When equipped with wheel 40-60);
		Main	AE-1 s/n all (When equipped with wheel 40-60);
		Main	HE-1 s/n all (When equipped with wheel 40-60);
		Main	J5A (Army L-4F) s/n all (When equipped with wheel 40-60);
		Main	J5A-80 s/n all (When equipped with wheel 40-60);
A		Main	J5B (Army L-4G) s/n all (When equipped with wheel 40-60):
		Main	J5C s/n all (When equipped with wheel 40-60);
		Main	PA-11 s/n all (When equipped with wheel 40-60);
		Main	PA-11S s/n all (When equipped with wheel 40-60);
		Main	PA-12 s/n all (When equipped with wheel 40-60);
		Main	PA-12S s/n all (When equipped with wheel 40-60);
		Main	PA-14 s/n all (When equipped with wheel 40-60);
		Main	PA-15 s/n all (When equipped with wheel 40-60);
		Main	PA-16 s/n all (When equipped with wheel 40-60);
		Main	PA-16 s/n all (When equipped with wheel 40-60);
		Main Main	PA-17 s/n all (When equipped with wheel 40-60);
		Main	PA-18 s/n all (When equipped with wheel 40-60);
		Main	PA-18 "105" (Special) s/n all (When equipped with wheel 40-60);
			- u-uu),



Rev	Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
_	MC154-02800	154-02800, 754-850	Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
				wheel 40-60);
Α			Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
				wheel 40-60);
Α			Main	PA-18 "150"* s/n 18-3781 thru 18-8309025 (When
				equipped with wheel 40-60);
Α			Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
				with wheel 40-60);
Α			Main	PA-18A s/n all (When equipped with wheel 40-60);
Α			Main	PA-18A "135" s/n all (When equipped with wheel 40-60);
Α			Main	PA-18A "150"* s/n 18-3781 thru 18-8309025 (When
				equipped with wheel 40-60);
Α			Main	PA-20 s/n all (When equipped with wheel 40-60);
Α			Main	PA-20 "115" s/n all (When equipped with wheel 40-60);
Α			Main	PA-20 "135" s/n all (When equipped with wheel 40-60);
			IVICIII	1 A-20 100 3/11 all (Which equipped with which 40-00),
Α	MC154-30010	154-30010, 754-855,	Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
		A-30010		equipped with wheel D-30625);
Α			Aux	PA-28-150 s/n all (When equipped with wheel D-30625);
Α			Aux	PA-28-160 s/n all (When equipped with wheel D-30625);
Α			Aux	PA-28-180 s/n all (When equipped with wheel D-30625);
Α			Aux	PA-28-181* s/n 28-7690001 thru 28-7890419 (When
				equipped with wheel D-30625);
Α			Aux	PA-28-181* s/n 28-7890420 thru 28-8690062 (When
				equipped with wheel D-30665);
Α			Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
				with wheel D-30665);
Α			Aux	PA-28-235* s/n 28-10003 thru 28-7710089 (When
				equipped with wheel D-30625);
Α			Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
				equipped with wheel D-30665);
Α			Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
				with wheel D-30665);
Α			Aux	PA-32-260* s/n 32-1 thru 32-7800006 (When equipped
				with wheel D-30625);
Α			Aux	PA-32-260* s/n 32-7800007 thru 32-7800008 (When
				equipped with wheel D-30665);
Α			Aux	PA-32-300* s/n 32-40000 thru 32-7840101 (When
				equipped with wheel D-30625);
Α			Aux	PA-32-300* s/n 32-7540102 thru 32-7940290 (When
				equipped with wheel D-30665);
Α			Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			, w.	equipped with wheel D-30665);
Α			Aux	PA-32-301FT s/n all (When equipped with wheel
			, lux	D-30665);
Α			Aux	PA-32-301T s/n all (When equipped with wheel D-30665);
			Aux	1 A-02-30 11 3/11 all (which equipped with which D-30003),



MC154-30010	Replaces 154-30010, 754-855,	<u>Location</u> Aux	Model and Serial Number Range PA-32-301XTC s/n all (When equipped with wheel
	A-30010		D-30665);
	= = = =	Aux	PA-34-200 s/n all (When equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7570001 thru 34-7870190 (When
			equipped with wheel D-30625);
		Aux	PA-34-200T* s/n 34-7870191 thru 34-8170092 (When
			equipped with wheel D-30665);
		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel D-30665);
		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel D-30665);
		Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel D-30665);
MC155-00100	155-00100, 155-1, 3023, 752-830	Main	J-3 s/n all (When equipped with wheel 40-84);
		Main	J-3 s/n all (When equipped with wheel 40-84B);
		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-84);
		Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-84B);
		Main	J3C-40 s/n all (When equipped with wheel 40-84);
		Main	J3C-40 s/n all (When equipped with wheel 40-84B);
		Main	J3C-50 s/n all (When equipped with wheel 40-84);
		Main	J3C-50 s/n all (When equipped with wheel 40-84B);
		Main	J3C-50S s/n all (When equipped with wheel 40-84);
		Main	J3C-50S s/n all (When equipped with wheel 40-84B);
		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-84);
		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-84B);
		Main	J3C-65S s/n all (When equipped with wheel 40-84);
		Main	J3C-65S s/n all (When equipped with wheel 40-84B);
		Main	J3F-50 s/n all (When equipped with wheel 40-84);
		Main	J3F-50 s/n all (When equipped with wheel 40-84B);
		Main	J3F-50S s/n all (When equipped with wheel 40-84);
		Main	J3F-50S s/n all (When equipped with wheel 40-84B);
		Main	J3F-60 s/n all (When equipped with wheel 40-84);
		Main	J3F-60 s/n all (When equipped with wheel 40-84B);
		Main	J3F-60S s/n all (When equipped with wheel 40-84);
		Main	J3F-60S s/n all (When equipped with wheel 40-84B);
		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84);
		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel 40-84B);
		Main	J3F-65S s/n all (When equipped with wheel 40-84);



Rev Part Number MC155-00100	Replaces	<u>Location</u> Main	Model and Serial Number Range J3F-65S s/n all (When equipped with wheel 40-84B);
IVIC 100-00 100	155-00100, 155-1, 3023, 752-830	iviaiil	Jor-Joo Sill all (Whiell equipped with wheel 40-04B);
Α	3023, 732-030	Main	J3L s/n all (When equipped with wheel 40-84);
A		Main	J3L s/n all (When equipped with wheel 40-84B);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel
			40-84);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel
			40-84B);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84);
A		Main	J3L-65S s/n all (When equipped with wheel 40-84B);
A		Main	J3L-S s/n all (When equipped with wheel 40-84);
A		Main	J3L-S s/n all (When equipped with wheel 40-84B);
A		Main	J3P s/n all (When equipped with wheel 40-84);
Α		Main	J3P s/n all (When equipped with wheel 40-84B);
A		Main	PA-11 s/n all (When equipped with wheel 40-84);
A		Main	PA-11 s/n all (When equipped with wheel 40-84B);
Α		Main	PA-11S s/n all (When equipped with wheel 40-84);
A		Main	PA-11S s/n all (When equipped with wheel 40-84B);
A		Main	PA-18 s/n all (When equipped with wheel 40-84);
A		Main	PA-18 s/n all (When equipped with wheel 40-84B);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-84B);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-84);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-84B);
A		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
			wheel 40-84);
Α		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
			equipped with wheel 40-84);
A		Main	PA-18 "150"* s/n 18-3771 thru 18-8309025 (When
_			equipped with wheel 40-84B);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84);
Α		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-84B);
A .		Main	PA-18A s/n all (When equipped with wheel 40-84);
A		Main	PA-18A s/n all (When equipped with wheel 40-84B);
A •		Main	PA-18A "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "135" s/n all (When equipped with wheel
•			40-84B);
Α		Main	PA-18A "150" s/n all (When equipped with wheel 40-84);
A		Main	PA-18A "150" s/n all (When equipped with wheel
			40-84B);
			40-84B);



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC155-00100	155-00100, 155-1,	Main	PA-20 s/n all (When equipped with wheel 40-84);
	3023, 752-830		, , , , , , , , , , , , , , , , , , , ,
A	·	Main	PA-20 s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "115" s/n all (When equipped with wheel 40-84B);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84);
A		Main	PA-20 "135" s/n all (When equipped with wheel 40-84B);
A		Aux	PA-22 s/n all (When equipped with wheel 40-76B);
A		Main	PA-22 s/n all (When equipped with wheel 40-84);
Α		Main	PA-22 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-108 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-135 s/n all (When equipped with wheel 40-84);
Α		Main	PA-22-135 s/n all (When equipped with wheel 40-84B);
Α		Main	PA-22-150 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-150 s/n all (When equipped with wheel 40-84B);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84);
A		Main	PA-22-160 s/n all (When equipped with wheel 40-84B);
A		Main	PA-23 s/n all (When equipped with wheel 3080A (40-3));
A		Aux	PA-23 s/n all (When equipped with wheel 40-76B);
A		Main	PA-23-160 s/n all (When equipped with wheel 3080A
			(40-3));
A		Aux	PA-23-160 s/n all (When equipped with wheel 40-76B);
A		Main	PA-23-235 s/n all (When equipped with wheel 3080B
			(40-4));
A		Main	PA-23-235 s/n all (When equipped with wheel 40-131);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-3737 (When
			equipped with wheel 3080B (40-4));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-7554149
			(When equipped with wheel 40-131);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-3738 thru 27-7554137
		_	(When equipped with wheel 3080D (40-116));
A		Aux	PA-23-250 (Navy UO-1)* s/n 27-4823 thru 27-8154030
			(When equipped with wheel 40-76B);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554141 thru
Å			27-7554149 (When equipped with wheel 3080D (40-116));
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554150 thru
A		N.4	27-8154030 (When equipped with wheel 40-131);
^		Main	PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped
Δ		Main	with wheel 3080B (40-4));
		Main	PA-E23-250* s/n 27-2505 thru 27-7554149 (When
A		Main	equipped with wheel 40-131);
·		Main	PA-E23-250* s/n 27-3738 thru 27-7554137 (When
A		Auv	equipped with wheel 3080D (40-116));
		Aux	PA-E23-250* s/n 27-4823 thru 27-7554168 (When
			equipped with wheel 40-76B);



-				W 11 10 11N 1 B
	art Number	Replaces	<u>Location</u>	Model and Serial Number Range
^ V	C155-00100	155-00100, 155-1,	Main	PA-E23-250* s/n 27-7554141 thru 27-7554149 (When
A		3023, 752-830	Main	equipped with wheel 3080D (40-116));
,,			Main	PA-E23-250* s/n 27-7554150 thru 27-7554168 (When
A			Main	equipped with wheel 40-131);
_ ^			Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
A			N.4 - :	with wheel 40-84);
_ ^			Main	PA-24-250* s/n 24-3307 thru 24-3687 (When equipped
A			Δ	with wheel 40-84B);
^			Aux	PA-24-260* s/n 24-5020 thru 24-5034 (When equipped
A			N.4 - :	with wheel 40-76B);
^			Main	PA-24-400* s/n 24-130 thru 26-148 (When equipped with
A			NA . *	wheel 40-90);
^			Main	PA-25-235* s/n 25-4172 thru 25-8156024 (When
				equipped with wheel 40-84A);
A			Main	PA-25-260* s/n 25-4415 thru 25-8156024 (When
				equipped with wheel 40-84A);
Α			Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
				equipped with wheel 40-86);
A			Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
				equipped with wheel 40-86B);
A			Main	PA-28-140* s/n 28-20521 thru 28-7725290 (When
			_	equipped with wheel 40-86F);
A			Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
			_	equipped with wheel 40-76B);
A			Aux	PA-28-140* s/n 28-7225335 thru 28-7725290 (When
				equipped with wheel 40-76F);
A			Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86);
Α			Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86B);
Α			Main	PA-28-150* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86F);
Α			Main	PA-28-151 s/n all (When equipped with wheel 40-86B);
Α			Main	PA-28-151 s/n all (When equipped with wheel 40-86F);
Α			Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86);
Α			Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86B);
Α			Main	PA-28-160* s/n 28-1761 thru 28-4377 (When equipped
				with wheel 40-86F);
Α			Main	PA-28-161* s/n 2816001 thru 2816119 (When equipped
				with wheel 40-86B);
Α			Main	PA-28-161* s/n 2816001 thru 2816119 (When equipped
				with wheel 40-86F);
A			Main	PA-28-161* s/n 2841001 thru 2841365 (When equipped
				with wheel 40-86B);



Rev Part Number	<u>Replaces</u>	<u>Location</u>	Model and Serial Number Range
^A MC155-00100	155-00100, 155-1,	Main	PA-28-161* s/n 2841001 thru 2841365 (When equipped
	3023, 752-830		with wheel 40-86F);
A		Main	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-86B);
A		Main	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-86F);
A		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86);
A		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86B);
A		Main	PA-28-180* s/n 28-1761 thru 28-7505260 (When
			equipped with wheel 40-86F);
A		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76B);
A		Aux	PA-28-180* s/n 28-7205244 thru 28-7505260 (When
			equipped with wheel 40-76F);
		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
			equipped with wheel 40-56B or 40-56);
		Aux	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
		7107	equipped with wheel 40-76F);
		Main	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
		Wall	equipped with wheel 40-86B);
		Main	PA-28-181* s/n 28-7690001 thru 28-8690062 (When
		IVICIII	•
		Aux	equipped with wheel 40-86F);
		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
		Ausz	with wheel 40-56B or 40-56);
		Aux	PA-28-181* s/n 2890001 thru 2890231 (When equipped
		Main	with wheel 40-76F);
		Main	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-86B);
		Main	PA-28-181* s/n 2890001 thru 2890231 (When equipped
			with wheel 40-86F);
		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-56B or 40-56);
		Main	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-86B);
		Main	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel 40-86F);
		Main	PA-28-201T s/n all (When equipped with wheel 40-86B);
		Main	PA-28-201T s/n all (When equipped with wheel 40-86F);
		Main	PA-28-235* s/n 28-10487 thru 28-7710089 (When
			equipped with wheel 40-86);
		Main	PA-28-235* s/n 28-10487 thru 28-7710089 (When
			equipped with wheel 40-86B);
A.		Main	PA-28-235* s/n 28-10487 thru 28-7710089 (When
			equipped with wheel 40-86F);



Rev Part Number A MC155-00100	Replaces 155-00100, 155-1,	Location Aux	Model and Serial Number Range PA-28-235* s/n 28-7210020 thru 28-7710089 (When
	3023, 752-830		equipped with wheel 40-76B);
A		Aux	PA-28-235* s/n 28-7210020 thru 28-7710089 (When
			equipped with wheel 40-76F);
A		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-56);
A		Main	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-86B);
A		Main	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel 40-86F);
A		Main	PA-28-236* s/n 28-8111001 thru 28-8611008 (When
			equipped with wheel 40-90A);
A		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-56);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-86B);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-86F);
A		Main	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel 40-90A);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
			equipped with wheel 40-84);
A		Main	PA-28R-180* s/n 28R-30005 thru 28R-7130005 (When
			equipped with wheel 40-84B);
A		Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
			equipped with wheel 40-86);
A		Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
			equipped with wheel 40-86B);
A		Main	PA-28R-180* s/n 28R-7130006 thru 28R-7130013 (When
_			equipped with wheel 40-86F);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84);
A		Main	PA-28R-200* s/n 28R-35001 thru 28R-7135109 (When
			equipped with wheel 40-84B);
A		Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
A			equipped with wheel 40-86);
^		Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
A		14.1	equipped with wheel 40-86B);
^		Main	PA-28R-200* s/n 28R-7135110 thru 28R-7635545 (When
A		N 4 - :	equipped with wheel 40-86F);
<u> </u>		Main	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
A		Main	equipped with wheel 40-86B);
5		Main	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
A		Main	equipped with wheel 40-86F);
,,		Main	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
			with wheel 40-86B);



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC155-00100	155-00100, 155-1,	Main	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
WIG 100 00 100	3023, 752-830	Widin	with wheel 40-86F);
A	3023, 732-030	Main	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
		Mair	with wheel 40-86B);
Α		Main	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
		Main	with wheel 40-86F);
A		Main	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
		Mairi	
A		Main	(When equipped with wheel 40-86B); PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
		IVIAIII	
A		Main	(When equipped with wheel 40-86F);
		Main	PA-28R-201T* s/n 2803001 thru 2803012 (When
A		N.4 - :	equipped with wheel 40-86B);
^		Main	PA-28R-201T* s/n 2803001 thru 2803012 (When
			equipped with wheel 40-86F);
A		Main	PA-28RT-201 s/n all (When equipped with wheel
			40-86B);
A		Main	PA-28RT-201 s/n all (When equipped with wheel
			40-86F);
A		Main	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-86B);
A		Main	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-86F);
A		Main	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-86B);
A		Main	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-86F);
A		Main	PA-30* s/n 30-2 thru 30-845 (When equipped with wheel
			40-34);
A		Main	PA-30* s/n 30-846 thru 30-2000 (When equipped with
			wheel 40-90);
A		Aux	PA-30* s/n 39-152 thru 30-2000 (When equipped with
			wheel 40-76B);
A		Main	PA-31 s/n all (When equipped with wheel 40-162);
A		Main	PA-31* s/n 31-5 thru 31-7300962 (When equipped with
			wheel 40-102);
A		Main	PA-31* s/n 31-5 thru 31-7712103 (When equipped with
			wheel 40-130);
A		Aux	PA-31* s/n 31-5 thru 31-8112037 (When equipped with
			wheel 40-76B);
A		Main	PA-31* s/n 31-7300963 thru 31-8312019 (When equipped
			with wheel 40-102A);
A		Main	PA-31* s/n 31-7812001 thru 31-8312019 (When equipped
		Trickin i	with wheel 40-130);
A		Aux	PA-31* s/n 31-8112038 thru 31-8312019 (When equipped
		Aux	with wheel 40-140);
A		Main	PA-31-300 s/n all (When equipped with wheel 40-162);
		IVICIII	17. 31-300 3/11 dii (Willell equipped willi willes 40-102),



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC155-00100	155-00100, 155-1,	Main	PA-31-300* s/n 31-5 thru 31-7300962 (When equipped
	3023, 752-830		with wheel 40-102);
A		Aux	PA-31-300* s/n 31-5 thru 31-8112037 (When equipped
			with wheel 40-76B);
A		Main	PA-31-300* s/n 31-7300963 thru 31-8312019 (When
			equipped with wheel 40-102A);
A		Main	PA-31-300* s/n 31-7812001 thru 31-8312019 (When
			equipped with wheel 40-130);
A		Aux	PA-31-300* s/n 31-8112038 thru 31-8312019 (When
			equipped with wheel 40-140);
A		Main	PA-31-325* s/n 31-7400990 thru 31-7712103 (When
			equipped with wheel 40-130);
A		Main	PA-31-325* s/n 31-7400990 thru 31-8112037 (When
			equipped with wheel 40-102A);
A		Aux	PA-31-325* s/n 31-7400990 thru 31-8112037 (When
		* 13071	equipped with wheel 40-76B);
A		Main	PA-31-325 s/n all (When equipped with wheel 40-162);
A		Main	PA-31-325* s/n 31-7812001 thru 31-8312019 (When
		IVICIII	equipped with wheel 40-130);
A		Aux	
		Aux	PA-31-325* s/n 31-8112038 thru 31-8312019 (When
A		Main	equipped with wheel 40-140);
		IVIAIII	PA-31-350* s/n 31-5001 thru 31-7652075 (When
A		Main	equipped with wheel 40-102A);
^		Main	PA-31-350* s/n 31-5001 thru 31-7652075 (When
Ā			equipped with wheel 40-130);
Α		Aux	PA-31-350* s/n 31-5001 thru 31-8152087 (When
			equipped with wheel 40-76B);
Α		Main	PA-31-350 s/n all (When equipped with wheel 40-162);
A		Main	PA-31-350* s/n 31-7652076 thru 31-8553002 (When
			equipped with wheel 40-130);
A		Aux	PA-31-350* s/n 31-8152088 thru 31-8553002 (When
			equipped with wheel 40-140);
A		Main	PA-31-350 (T1020) s/n all (When equipped with wheel
			40-130);
A		Aux	PA-31-350 (T1020) s/n all (When equipped with wheel
			40-140);
A		Aux	PA-31P s/n all (When equipped with wheel 40-140);
A		Aux	PA-31P s/n all (When equipped with wheel 40-76B);
A		Main	PA-31P-350 s/n all (When equipped with wheel 40-130);
A		Aux	PA-31P-350 s/n all (When equipped with wheel 40-140);
A		Aux	PA-31T s/n all (When equipped with wheel 40-140);
A		Aux	PA-31T2 s/n all (When equipped with wheel 40-140);
A		Aux	PA-31T3 (T1040) s/n all (When equipped with wheel
		-	40-140);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-260 s/n all (When equipped with wheel 40-90);
		IVIGIII	17. 02 200 3/11 dil (VVIICII equipped Willi Wilcei 40-30),



Rev Part Number	<u>Replaces</u>	<u>Location</u>	Model and Serial Number Range
^A MC155-00100	155-00100, 155-1,	Main	PA-32-260 s/n all (When equipped with wheel 40-90A);
	3023, 752-830	_	
Α		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
_			equipped with wheel 40-56B or 40-56);
Α		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
			equipped with wheel 40-76B);
A		Aux	PA-32-260* s/n 32-7200030 thru 32-7800008 (When
			equipped with wheel 40-76F);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90);
A		Main	PA-32-300 s/n all (When equipped with wheel 40-90A);
A		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-56B or 40-56);
A		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-76B);
A		Aux	PA-32-300* s/n 32-7240101 thru 32-7940290 (When
			equipped with wheel 40-76F);
A		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-120C);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-56B or 40-56);
A		Main	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-90A);
A		Main	PA-32-301FT s/n all (When equipped with wheel
			40-120C);
A		Aux	PA-32-301FT s/n all (When equipped with wheel 40-56B
			or 40-56);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-120C);
A		Aux	PA-32-301T s/n all (When equipped with wheel 40-56B or
			40-56);
A		Main	PA-32-301T s/n all (When equipped with wheel 40-90A);
4		Main	PA-32-301XTC s/n all (When equipped with wheel
			40-120C);
A		Aux	PA-32-301XTC s/n all (When equipped with wheel
			40-56B or 40-56);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-120);
A		Main	PA-32R-300 s/n all (When equipped with wheel 40-90A);
A		Main	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-90A);
A		Main	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-120C);
A		Main	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel 40-120);
			/



Rev Part Number	Replaces	Location	Model and Serial Number Range
A MC155-00100	155-0010 ⁰ , 155-1,	Main	PA-32RT-300 s/n all (When equipped with wheel
	3023, 752-830		40-120C);
A		Main	PA-32RT-300 s/n all (When equipped with wheel
			40-90A);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-120C);
A		Main	PA-32RT-300T s/n all (When equipped with wheel
			40-90A);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-120C);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-90);
A		Main	PA-34-200 s/n all (When equipped with wheel 40-90A);
A		Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
			equipped with wheel 40-76B);
A		Aux	PA-34-200* s/n 34-7250217 thru 34-7450220 (When
			equipped with wheel 40-76F);
A		Main	PA-34-200T s/n all (When equipped with wheel 40-120C);
A		Aux	PA-34-200T s/n all (When equipped with wheel 40-56B or
			40-56);
A		Aux	PA-34-200T s/n all (When equipped with wheel 40-76F);
A		Main	PA-34-200T s/n all (When equipped with wheel 40-90A);
A		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-120C);
A		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-56B or 40-56);
A		Main	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel 40-90A);
A		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-120C);
A		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-56B or 40-56);
A		Main	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel 40-90A);
A		Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-120C);
A		Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-56B or 40-56);
A		Main	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel 40-90A);
A		Main	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
			with wheel 40-120C);
A		Aux	PA-34-220T* s/n 3447001 thru 3447029 (When equipped
			with wheel 40-56B or 40-56);
A		Main	PA-34-220T* s/n 3449001 thru 3449999 (When equipped
			with wheel 40-120C);
			•



3023, 752-830 with wheel 40	erial Number Range s/n 3449001 thru 3449999 (When equipped
A Main PA-36-285 s/ A Main PA-36-307 s/ A Aux PA-38-311 s/ A Main PA-38-112 s/ A Main PA-38-112 s/ A Main PA-38-112 s/ A Main PA-42-700° s A Aux PA-42-700° s A Aux PA-42-720° s A Aux PA-44-180° s A Main PA-44-180° s A Main PA-44-180° s A Main PA-44-180° s With wheel 4 Aux PA-44-180° s Wit	0-56B or 40-56);
Main PA-36-300 s/ Main PA-36-375 y/ A Main PA-38-112 s/ A Main PA-38-112 s/ A Main PA-38-112 s/ A Main PA-38-112 s/ A Main PA-39 s/n all A Aux PA-42-1001 A Aux PA-42-700 s/ equipped wit A Aux PA-42-720 s/ equipped wit A Aux PA-42-720 s/ equipped wit A Aux PA-42-720 s/ equipped wit A Main PA-44-180 s/ equipped wit A Main PA-44-180 s/ with wheel 44	n all (When equipped with wheel 40-101);
A Main PA-36-375 s/s A Aux PA-38-112 s/s A Main PA-38-112 s/s A Main PA-39 s/n all A Aux PA-42 s/n all A Aux PA-42-1000 s/s A Aux PA-42-720° s/equipped wit A Aux PA-42-720° s/equipped wit A Aux PA-42-720° s/equipped wit A Main PA-44-180° s/equip	n all (When equipped with wheel 40-101);
Aux PA-38-112 s/ Main PA-38 -112 s/ Main PA-39 s/n sll Aux PA-42 s/n all Aux PA-42-700* sequipped wit Aux PA-42-720* sequipped wit Aux PA-42-1720* sequipped wit Aux PA-42-180* sequipped wit Aux PA-44-180* sequipped wit sequ	n all (When equipped with wheel 40-101);
Main PA-38-112 s/ A Main PA-39 s/n all A Aux PA-42 s/n all A Aux PA-42-700° s	n all (When equipped with wheel 40-56);
A Main PA-39 s/n all A Aux PA-42 s/n all A Aux PA-42-1000 sequipped with A Aux PA-42-720° sequipped with A Aux PA-42-720° sequipped with A Aux PA-42-720° sequipped with A Main PA-44-180° sequipped with wheel 4th A Main PA-46-310° sequipped with wheel 4th A Main PA-46-310° sequipped with wheel 4th A Main PA-46-310° sequipped with wheel 4th	n all (When equipped with wheel 40-59D);
A Aux PA-42 s/n all Aux PA-42 s/n all Aux PA-42-1000 s equipped wit PA-42-720° s equipped wit PA-42-720° s equipped wit PA-42-720° s equipped wit PA-42-720° s equipped wit PA-42-720° s equipped wit PA-44-180° s with wheel 44 PA-44-180° s with	(When equipped with wheel 40-90);
Aux PA-42-1000 a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-42-720° a quipped with Aux PA-44-180° a quipped with Aux PA-46-310° a quipped with Aux PA	(When equipped with wheel 40-140);
Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-42-720° sequipped with Aux PA-44-180° sequipped with Aux PA-46-310° sequipped with Aux PA-46-310° sequipped with Aux PA-46-310° sequipped with PA-46-310° sequipped with PA-46-310° sequipped with Aux PA-46-310° sequipped with PA-46-310° seq	s/n all (When equipped with wheel 40-140);
A Aux PA-42-720° s	s/n 42-5501003 thru 42-5501039 (When
A Aux PA-42-720° s equipped wit equipped wit A Aux PA-42-720° s equipped wit A Aux PA-42-720° s equipped wit A Aux PA-42-720° s equipped wit equipped wit equipped wit A Main PA-44-180° s equipped wit equipped wit a Main PA-44-180° s equipped wit with wheel 4 A Main PA-44-180° s with wheel 44 A Main PA-44-180° s with wheel 47 A Main PA-44-180° s with wheel 48 A Main PA-44-180° s with wheel 49 A Main PA-44-180° s with wheel 49 A Main PA-44-180° s equipped with A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 49 A Main PA-46-310° s equipped with wheel 40 A Main PA-46	•
A	s/n 42-8301001 thru 42-8301002 (When
A Aux PA-42-720* sequipped with a Aux PA-42-720R Main PA-44-180* sequipped with PA-44-180* sequi	•
A Aux PA-42-720 R equipped wit A Aux PA-42-720 R Main PA-44-180* s equipped wit A Main PA-44-180* s equipped wit A Main PA-44-180* s equipped wit A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-44-180* s with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P* with wheel 40 A Main PA-46-310P*	s/n 42-5501040 thru 42-5501060 (When
A Aux PA-42-720R A Main PA-44-180* sequipped with PA-44-180* sequipped	•
A Main PA-44-180* sequipped with equipped with equipped with equipped with equipped with equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with wheel 40 states are equipped with equipped with equipped with equipped with equipped with equipped with wheel 40 states are equipped with eq	s/n all (When equipped with wheel 40-140);
Requipped with a continuous part of the con	s/n 44-7995001 thru 44-8195026 (When
Main PA-44-180*s equipped wit PA-44-180*s equipped wit PA-44-180*s equipped wit PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-44-180*s with wheel 44 Main PA-46-310P*s equipped wit Main PA-46-310P*s with wheel 44 Main PA-46-350P	
Main PA-44-180*s equipped with A Main PA-44-180*s equipped with wheel 40	•
Main PA-44-180* s equipped with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-46-310P* equipped with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* A Main PA-46-350P	s/n 44-7995001 thru 44-8195026 (When
Main PA-44-180* s equipped with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-46-310P* equipped with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-350P*	•
Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* Main PA-46-310P* with wheel 40 Main PA-46-310P* With wheel 40 Main PA-46-310P* With wheel 40 Main PA-46-310P* With wheel 40 Main PA-46-350P	s/n 44-7995001 thru 44-8195026 (When
Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P*	• •
A Main PA-44-180* s with wheel 40 with which with wheel 40 with wheel 40 with which with wheel 40 with which which with which which with which which with which with which which with which	s/n 4495001 thru 4495013 (When equipped
Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-350P*	
A Main PA-44-180* s with wheel 40 with which wh	s/n 4495001 thru 4495013 (When equipped
Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180* s with wheel 40 Main PA-44-180T s Main PA-44-180T s Main PA-44-180T s Main PA-44-180T s Main PA-46-310P* equipped with wheel 40 Main PA-46-310P* with wheel 40 Main PA-46-350P* Main PA-46-350P*	•
A Main PA-44-180* s with wheel 40 with wheel 40 with wheel 40 with wheel 40 with wheel 40 with wheel 40 with wheel 40 with wheel 40 main A Main PA-44-180T s with wheel 40 main A Main PA-44-180T s with wheel 40 with which which wheel 40 with which	s/n 4495001 thru 4495013 (When equipped
Main PA-44-180* s with wheel 40 A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-46-310P* equipped wit A Main PA-46-310P* with wheel 40 A Main PA-46-350P	•
A Main PA-44-180* s with wheel 40 with which	s/n 4496001 thru 4496999 (When equipped
Main PA-44-180 s with wheel 40 A Main PA-44-180T s A Main PA-44-180T s A Main PA-44-180T s A Main PA-46-310P* equipped wit A Main PA-46-310P* with wheel 40 A Main PA-46-350P	
A Main PA-44-180T : A Main PA-44-180T : A Main PA-46-310P* A Main PA-46-310P* A Main PA-46-310P* With wheel 40 With wheel 40 A Main PA-46-350P	s/n 4496001 thru 4496999 (When equipped
A Main PA-44-180T s A Main PA-46-310P* A Main PA-46-310P* B Main PA-46-310P* With wheel 40 With wheel 40 A Main PA-46-350P	
A Main PA-44-180T strength A Main PA-46-310P* equipped with A Main PA-46-310P* with wheel 40 strength A Main PA-46-350P	s/n all (When equipped with wheel 40-120);
A Main PA-46-310P* equipped wit equipped wit with wheel 40 with wheel 40 with wheel 40 PA-46-350P A Main PA-46-350P	s/n all (When equipped with wheel 40-120C);
equipped wit Main PA-46-310P* with wheel 40 Main PA-46-350P	s/n all (When equipped with wheel 40-90A);
Main PA-46-310P* with wheel 40 Main PA-46-350P	s/n 46-8408001 thru 46-8608067 (When
with wheel 40 Main PA-46-350P	h wheel 40-120C);
Main PA-46-350P	s/n 4608001 thru 4608140 (When equipped
wheel 40-120	(w/ G1000) s/n all (When equipped with
	· ·
	(w/o G1000)* s/n 4622001 thru 4622200
, , ,	ped with wheel 40-120C);
	(w/o G1000)* s/n 4636001 thru 4636999
(When equip	ped with wheel 40-120C);



Rev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
^A MC155-00100	155-00100, 155-1,	Main	PA-46-500TP (w/ G1000) s/n all (When equipped with
	3023, 752-830		wheel 40-142);
A		Main	PA-46-500TP (w/o G1000) s/n all (When equipped with
			wheel 40-142);
A		Main	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-120C);
Α		Main	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-120C);
A		Main	PA-60-600 s/n all (When equipped with wheel 40-124);
A		Aux	PA-60-600 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-60-600 s/n all (When equipped with wheel 40-76F);
A		Main	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
			equipped with wheel 40-124);
A		Aux	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
			equipped with wheel 40-76B);
A		Aux	PA-60-600 (Ted Smith Aerostar 600) s/n all (When
			equipped with wheel 40-76F);
A		Main	PA-60-601 s/n all (When equipped with wheel 40-124);
A		Aux	PA-60-601 s/n all (When equipped with wheel 40-76B);
A		Aux	PA-60-601 s/n all (When equipped with wheel 40-76F);
A		Main	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
		Walli	equipped with wheel 40-124);
A		Aux	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
		Aux	equipped with wheel 40-76B);
A		Aux	
		Aux	PA-60-601 (Ted Smith Aerostar 601) s/n all (When
A		Main	equipped with wheel 40-76F);
A			PA-60-601P s/n all (When equipped with wheel 40-124);
Α		Aux	PA-60-601P s/n all (When equipped with wheel 40-76B);
Α		Aux	PA-60-601P s/n all (When equipped with wheel 40-76F);
^		Main	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
A			equipped with wheel 40-124);
A		Aux	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
_			equipped with wheel 40-76B);
A		Aux	PA-60-601P (Ted Smith Aerostart 601P) s/n all (When
			equipped with wheel 40-76F);
A		Main	PA-60-602P s/n all (When equipped with wheel 40-124);
A		Aux	PA-60-602P s/n all (When equipped with wheel 40-76B);
Α		Aux	PA-60-602P s/n all (When equipped with wheel 40-76F);
A		Main	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-124);
A		Aux	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-76B);
A		Aux	PA-60-602P (Ted Smith Aerostar 602P) s/n all (When
			equipped with wheel 40-76F);



Rev Part Number MC155-00200	Replaces 155-00200, 155-2,	<u>Location</u> Main	Model and Serial Number Range J-3 s/n all (When equipped with wheel 40-60);
	756-008		o o s a (vo, oqu.ppou mar m.oo. to oo),
A	700 000	Main	J3 (Converted TG-8 Glider) s/n all (When equipped with
			wheel 40-60);
A		Main	J3C-40 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50 s/n all (When equipped with wheel 40-60);
A		Main	J3C-50S s/n all (When equipped with wheel 40-60);
A		Main	J3C-65 (Army L-4,L-4A,B,H,J, Navy NE-1,2) s/n all
			(When equipped with wheel 40-60);
A		Main	J3C-65S s/n all (When equipped with wheel 40-60);
A		Main	J3F-50 s/n all (When equipped with wheel 40-60);
A		Main	J3F-50S s/n all (When equipped with wheel 40-60);
A		Main	J3F-60 s/n all (When equipped with wheel 40-60);
A		Main	J3F-60S s/n all (When equipped with wheel 40-60);
A		Main	J3F-65 (Army L-4D) s/n all (When equipped with wheel
			40-60);
A		Main	J3F-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L s/n all (When equipped with wheel 40-60);
A		Main	J3L-65 (Army L-4C) s/n all (When equipped with wheel
			40-60);
A		Main	J3L-65S s/n all (When equipped with wheel 40-60);
A		Main	J3L-S s/n all (When equipped with wheel 40-60);
A		Main	J3P s/n all (When equipped with wheel 40-60);
A		Main	J4 s/n all (When equipped with wheel 40-60);
A		Main	J4A s/n all (When equipped with wheel 40-60);
A		Main	J4A-S s/n all (When equipped with wheel 40-60);
A		Main	J4B s/n all (When equipped with wheel 40-60);
A		Main	J4E (Army L-4E) s/n all (When equipped with wheel
			40-60);
A		Main	J4F s/n all (When equipped with wheel 40-60);
A		Main	AE-1 s/n all (When equipped with wheel 40-60);
A		Main	HE-1 s/n all (When equipped with wheel 40-60);
A		Main	J5A (Army L-4F) s/n all (When equipped with wheel
			40-60);
A		Main	J5A-80 s/n all (When equipped with wheel 40-60);
A		Main	J5B (Army L-4G) s/n all (When equipped with wheel
			40-60);
A		Main	J5C s/n all (When equipped with wheel 40-60);
A		Main	PA-11 s/n all (When equipped with wheel 40-60);
A		Main	PA-11S s/n all (When equipped with wheel 40-60);
A		Main	PA-12 s/n all (When equipped with wheel 40-60);
A		Main	PA-12S s/n all (When equipped with wheel 40-60);
A		Main	PA-14 s/n all (When equipped with wheel 40-60);
A		Main	PA-15 s/n all (When equipped with wheel 40-60);
A		Main	PA-16 s/n all (When equipped with wheel 40-60);
		Main	PA-16S s/n all (When equipped with wheel 40-60);
A			



ev Part Number MC155-00200	<u>Replaces</u> 155-00200, 155-2,	<u>Location</u> Main	Model and Serial Number Range PA-17 s/n all (When equipped with wheel 40-60);
	756-008		
A	700 000	Main	PA-18 s/n all (When equipped with wheel 40-60);
A		Main	PA-18 "105" (Special) s/n all (When equipped with wheel
			40-60);
A		Main	PA-18 "125" (Army L-21A) s/n all (When equipped with
			wheel 40-60);
A		Main	PA-18 "135" (Army L-21B) s/n all (When equipped with
			wheel 40-60);
A		Main	PA-18 "150"* s/n 18-3781 thru 18-8309025 (When
			equipped with wheel 40-60);
A		Main	PA-18 "150"* s/n 1809001 thru 1809113 (When equipped
			with wheel 40-60);
A		Main	PA-18A s/n all (When equipped with wheel 40-60);
A.		Main	PA-18A "135" s/n all (When equipped with wheel 40-60);
A.		Main	PA-18A "150"* s/n 18-3781 thru 18-8309025 (When
			equipped with wheel 40-60);
\		Main	PA-20 s/n all (When equipped with wheel 40-60);
1		Main	PA-20 "115" s/n all (When equipped with wheel 40-60);
		Main	PA-20 "135" s/n all (When equipped with wheel 40-60);
		Aux	PA-28-151 s/n all (When equipped with wheel 40-77);
		Aux	PA-28-151 s/n all (When equipped with wheel 40-77B);
<u>.</u>		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			with wheel 40-77);
		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			with wheel 40-77B);
<u>.</u>		Aux	PA-28-161* s/n 2841001 thru 2841365 (When equipped
			with wheel 40-77B);
<u>.</u>		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-77);
		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel 40-77B);
		Aux	PA-28-201T s/n all (When equipped with wheel 40-77);
		Aux	PA-28-201T s/n all (When equipped with wheel 40-77B);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77A);
		Aux	PA-28R-180 s/n all (When equipped with wheel 40-77B);
		Aux	PA-28R-200 s/n all (When equipped with wheel 40-77);
		Aux	PA-28R-200 s/n all (When equipped with wheel 40-77A);
		Aux	PA-28R-200 s/n all (When equipped with wheel 40-77B);
L		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
			equipped with wheel 40-77);
		Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
			equipped with wheel 40-77B);
1		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
			with wheel 40-77);



ev Part Number	Replaces	<u>Location</u>	Model and Serial Number Range
MC155-00200	155-00200, 155-2,	Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
	756-008		with wheel 40-77B);
		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
			with wheel 40-77);
		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
			with wheel 40-77B);
		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel 40-77);
		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
			(When equipped with wheel 40-77B);
		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
		Aux	,
		Aux	equipped with wheel 40-77);
		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
		A	equipped with wheel 40-77B);
		Aux	PA-28RT-201 s/n all (When equipped with wheel 40-77);
		Aux	PA-28RT-201 s/n all (When equipped with wheel
			40-77B);
		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77);
		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
			(When equipped with wheel 40-77B);
		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-77);
		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
			equipped with wheel 40-77B);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel 40-77);
		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
		, tax	equipped with wheel 40-77B);
		Aux	PA-32-301T s/n all (When equipped with wheel 40-77);
		Aux	PA-32-301T s/n all (When equipped with wheel 40-77B);
		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77);
		Aux	PA-32R-300 s/n all (When equipped with wheel 40-77B);
		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equippe
			with wheel 40-77);
		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
			with wheel 40-77B);
		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-77);
		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
			with wheel 40-77B);
		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
			equipped with wheel 40-77);
		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
		-	equipped with wheel 40-77B);
			equipped with whool to 11D),



Part Number MC155-00200	Replaces 155-00200, 155-2,	<u>Location</u> Aux	Model and Serial Number Range PA-32R-301T* s/n 3257001 thru 3257999 (When
	756-008		equipped with wheel 40-77);
		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
			equipped with wheel 40-77B);
		Aux	PA-32RT-300 s/n all (When equipped with wheel 40-77);
		Aux	PA-32RT-300 s/n all (When equipped with wheel
			40-77B);
		Aux	PA-32RT-300T s/n all (When equipped with wheel 40-77)
		Aux	PA-32RT-300T s/n all (When equipped with wheel
			40-77B);
		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
		Tux	equipped with wheel 40-77B);
		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
		Aux	, , , , , , , , , , , , , , , , , , , ,
		Aux	with wheel 40-77B);
		Aux	PA-34-220T* s/n 3448001 thru 3448037 (When equipped
		Ausz	with wheel 40-77B);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
		A	equipped with wheel 40-77);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77B);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
			equipped with wheel 40-77C);
		Main	PA-38-112 s/n all (When equipped with wheel 40-78B);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-77);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
			equipped with wheel 40-77B);
		Aux	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-77);
		Aux	PA-44-180* s/n 4495001 thru 4495013 (When equipped
			with wheel 40-77B);
		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-77);
		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
			with wheel 40-77B);
		Aux	PA-44-180T s/n all (When equipped with wheel 40-77);
		Aux	PA-44-180T s/n all (When equipped with wheel 40-77B);
		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
			equipped with wheel 40-77);
		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
		Tux	equipped with wheel 40-77B);
		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
		Λux	, , , , , , , , , , , , , , , , , , , ,
		Ausz	with wheel 40-77);
		Aux	PA-46-310P* s/n 4608001 thru 4608140 (When equipped
			with wheel 40-77B);



ev Part Number MC155-00200	Replaces 155-00200, 155-2,	<u>Location</u> Aux	Model and Serial Number Range PA-46-350P (w/ G1000) s/n all (When equipped with
	756-008		wheel 40-77);
A		Aux	PA-46-350P (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-77);
A		Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
			(When equipped with wheel 40-77B);
A		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		Aux	(When equipped with wheel 40-77);
A		Aux	
		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
A		A	(When equipped with wheel 40-77B);
^		Aux	PA-46-500TP (w/ G1000) s/n all (When equipped with
A			wheel 40-77G);
A		Aux	PA-46-500TP (w/o G1000) s/n all (When equipped with
			wheel 40-77G);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-77);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
			wheel 40-77B);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-77);
A		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel 40-77B);
A MC155-00300	155-00300	Main	PA-23 s/n all (When equipped with wheel 3080A (40-3));
A		Main	PA-23-160 s/n all (When equipped with wheel 3080A
			(40-3));
A		Main	PA-23-235 s/n all (When equipped with wheel 3080B
		Main	(40-4));
A		Main	PA-23-235 s/n all (When equipped with wheel 40-131);
A			
		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-3737 (When
A		Main	equipped with wheel 3080B (40-4));
_		Main	PA-23-250 (Navy UO-1)* s/n 27-1 thru 27-7554149
A			(When equipped with wheel 40-131);
A		Main	PA-23-250 (Navy UO-1)* s/n 27-3738 thru 27-7554137
			(When equipped with wheel 3080D (40-116));
		Main	PA-23-250 (Navy UO-1)* s/n 27-7554141 thru
A			27-7554149 (When equipped with wheel 3080D (40-116));
A			
A		Main	PA-23-250 (Navy UO-1)* s/n 27-7554150 thru
		Main	PA-23-250 (Navy UO-1)* s/n 27-7554150 thru 27-8154030 (When equipped with wheel 40-131);
		Main Main	· · · · · · · · · · · · · · · · · · ·
A			27-8154030 (When equipped with wheel 40-131); PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped
A		Main	27-8154030 (When equipped with wheel 40-131); PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped with wheel 3080B (40-4));
A A			27-8154030 (When equipped with wheel 40-131); PA-E23-250* s/n 27-2505 thru 27-3737 (When equipped



ev Part Number MC155-00300	Replaces 155-00300	<u>Location</u> Main	Model and Serial Number Range PA-E23-250* s/n 27-3738 thru 27-7554137 (When
			equipped with wheel 3080D (40-116));
A.		Main	PA-E23-250* s/n 27-7554141 thru 27-7554149 (When
			equipped with wheel 3080D (40-116));
		Main	PA-E23-250* s/n 27-7554150 thru 27-7554168 (When
			equipped with wheel 40-131);
MC155-04400	155-04400, 155-44,	Main	PA-31-350* s/n 31-5001 thru 31-8052030 (When
	762-614		equipped with wheel 40-141);
		Main	PA-31-350* s/n 31-8052031 thru 31-8553002 (When
			equipped with wheel 40-141);
		Main	PA-31-350 (T1020) s/n all (When equipped with wheel
			40-141);
		Main	PA-31P s/n all (When equipped with wheel 40-141);
		Main	PA-31P-350 s/n all (When equipped with wheel 40-141);
		Main	PA-31T s/n all (When equipped with wheel 40-106);
		Main	PA-31T1 s/n all (When equipped with wheel 40-106A);
		Main	PA-31T1* s/n 31T-7804001 thru 31T-8104101 (When
			equipped with wheel 40-106);
		Main	PA-31T1* s/n 31T-8304001 thru 31T-1104017 (When
			equipped with wheel 40-106);
		Main	PA-31T2 s/n all (When equipped with wheel 40-167);
		Main	PA-31T3 (T1040) s/n all (When equipped with wheel
		N.4 - i	40-167);
		Main	PA-31T3 (T1040) s/n all (When equipped with wheel
			40-167A);
		Main	PA-42 s/n all (When equipped with wheel 40-166);
		Main	PA-42-1000 s/n all (When equipped with wheel 40-176);
		Main	PA-42-720* s/n 42-5501003 thru 42-5501039 (When
		Main	equipped with wheel 40-166);
		Main	PA-42-720* s/n 42-8301001 thru 42-8301002 (When
		Main	equipped with wheel 40-166);
		IVIAIII	PA-42-720* s/n 42-5501040 thru 42-5501060 (When
		Main	equipped with wheel 40-166); PA-42-720R s/n all (When equipped with wheel 40-166);
		IVIAIII	1 A-42-72010 3/11 all (Whieli equipped with wheel 40-100),
MC155-11800	155-11800, 762-561, A-1636-23	Aux	PA-28-151 s/n all (When equipped with wheel D-30500);
		Aux	PA-28-161* s/n 2816001 thru 2816119 (When equipped
			with wheel D-30500);
		Aux	PA-28-161* s/n 2842001 thru 2842999 (When equipped
			with wheel D-30500);
		Aux	PA-28-201T s/n all (When equipped with wheel D-30500);
		Aux	PA-28R-180 s/n all (When equipped with wheel
			D-30500);
		Aux	PA-28R-200 s/n all (When equipped with wheel
		7 tux	zor zor zor zor (or ogarppou mar moor



Rev Part Number	<u>Replaces</u>	<u>Location</u>	Model and Serial Number Range
^A MC155-11800	155-11800, 762-561,	Aux	PA-28R-201* s/n 28R-7737002 thru 28R-7837317 (When
	A-1636-23	_	equipped with wheel D-30500);
A		Aux	PA-28R-201* s/n 2837001 thru 2837061 (When equipped
			with wheel D-30500);
A		Aux	PA-28R-201* s/n 2844001 thru 2844999 (When equipped
_			with wheel D-30500);
A		Aux	PA-28R-201T* s/n 28R-7703001 thru 28R-7803373
_			(When equipped with wheel D-30500);
A		Aux	PA-28R-201T* s/n 2803001 thru 2803012 (When
		_	equipped with wheel D-30500);
A		Aux	PA-28RT-201 s/n all (When equipped with wheel
		_	D-30500);
A		Aux	PA-28RT-201T* s/n 28R-7931001 thru 28R-8631005
		_	(When equipped with wheel D-30500);
A		Aux	PA-28RT-201T* s/n 2831001 thru 2831038 (When
A			equipped with wheel D-30500);
^		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
A			equipped with wheel D-30500);
A		Aux	PA-32-301T s/n all (When equipped with wheel D-30500);
^		Aux	PA-32R-300 s/n all (When equipped with wheel
A			D-30500);
		Aux	PA-32R-301* s/n 3213001 thru 3213103 (When equipped
A		A	with wheel D-30500);
_ ^		Aux	PA-32R-301* s/n 3246001 thru 3246999 (When equipped
A		A	with wheel D-30500);
_ ^		Aux	PA-32R-301T* s/n 3229001 thru 3229003 (When
A		Δ	equipped with wheel D-30500);
<u> </u>		Aux	PA-32R-301T* s/n 3257001 thru 3257999 (When
A		Δ	equipped with wheel D-30500);
		Aux	PA-32RT-300 s/n all (When equipped with wheel
A		Ausz	D-30500);
		Aux	PA-32RT-300T s/n all (When equipped with wheel
A		Ausz	D-30500);
		Aux	PA-38-112* s/n 38-78A0001 thru 38-80A0198 (When
A		Aux	equipped with wheel D-30500);
		Aux	PA-44-180* s/n 44-7995001 thru 44-8195026 (When
A		Aux	equipped with wheel D-30500); PA-44-180* s/n 4495001 thru 4495013 (When equipped
		Aux	with wheel D-30500);
A		Aux	PA-44-180* s/n 4496001 thru 4496999 (When equipped
		Aux	with wheel D-30500);
A		Aux	PA-44-180T s/n all (When equipped with wheel D-30500);
A		Aux	PA-46-310P* s/n 46-8408001 thru 46-8608067 (When
		AUA	equipped with wheel D-30500);
A		Aux	equipped with wheel D-30500); PA-46-310P* s/n 4608001 thru 4608140 (When equipped
		AUA	with wheel D-30500);
			with wheel D-30000),



Rev Part Number MC155-11800	Replaces 155-11800, 762-561,	<u>Location</u> Aux	Model and Serial Number Range PA-46-350P (w/ G1000) s/n all (When equipped with
1000	A-1636-23	Nux	wheel D-30500);
A	A-1030-23	Aux	PA-46-350P (w/o G1000)* s/n 4622001 thru 4622200
		Aux	(When equipped with wheel D-30500);
A		Aux	PA-46-350P (w/o G1000)* s/n 4636001 thru 4636999
		Aux	(When equipped with wheel D-30500);
A		Aux	PA-46R-350T (w/ G1000) s/n all (When equipped with
		Aux	, , , , , , , , , , , , , , , , , , , ,
A		Ausz	wheel D-30500);
		Aux	PA-46R-350T (w/o G1000) s/n all (When equipped with
			wheel D-30500);
^A MC155-11900	155-11900, 762-562,	Aux	PA-28-140* s/n 28-20002 thru 28-7725290 (When
	A-1636-24	_	equipped with wheel D-30625);
Α		Aux	PA-28-150 s/n all (When equipped with wheel D-30625);
Α		Aux	PA-28-160 s/n all (When equipped with wheel D-30625);
A		Aux	PA-28-180 s/n all (When equipped with wheel D-30625);
A		Aux	PA-28-181* s/n 28-7690001 thru 28-7890419 (When
			equipped with wheel D-30625);
A		Aux	PA-28-181* s/n 28-7890420 thru 28-8690062 (When
			equipped with wheel D-30665);
A		Aux	PA-28-181* s/n 2843001 thru 2843999 (When equipped
			with wheel D-30665);
A		Aux	PA-28-235* s/n 28-10003 thru 28-7710089 (When
			equipped with wheel D-30625);
A		Aux	PA-28-236* s/n 28-7911001 thru 28-8611008 (When
			equipped with wheel D-30665);
A		Aux	PA-28-236* s/n 2811001 thru 2811050 (When equipped
			with wheel D-30665);
A		Aux	PA-32-260* s/n 32-1 thru 32-7800006 (When equipped
			with wheel D-30625);
A		Aux	PA-32-260* s/n 32-7800007 thru 32-7800008 (When
			equipped with wheel D-30665);
A		Aux	PA-32-300* s/n 32-40000 thru 32-7840101 (When
			equipped with wheel D-30625);
A		Aux	PA-32-300* s/n 32-7540102 thru 32-7940290 (When
			equipped with wheel D-30665);
A		Aux	PA-32-301* s/n 32-8006002 thru 32-8606023 (When
			equipped with wheel D-30665);
A		Aux	PA-32-301FT s/n all (When equipped with wheel
			D-30665);
A		Aux	PA-32-301T s/n all (When equipped with wheel D-30665);
A		Aux	PA-32-301XTC s/n all (When equipped with wheel
			D-30665);
A		Aux	PA-34-200 s/n all (When equipped with wheel D-30625);
A		Aux	PA-34-200T* s/n 34-7570001 thru 34-7870190 (When
			equipped with wheel D-30625);
			equipped man mison b cochoj;



Rev Part Number	Replaces	Location	Model and Serial Number Range
^A MC155-11900	155-11900, 762-562,	Aux	PA-34-200T* s/n 34-7870191 thru 34-8170092 (When
	A-1636-24		equipped with wheel D-30665);
A		Aux	PA-34-220T* s/n 34-8133001 thru 34-8633031 (When
			equipped with wheel D-30665);
A		Aux	PA-34-220T* s/n 3433001 thru 3433172 (When equipped
			with wheel D-30665);
A		Aux	PA-34-220T* s/n 3448001 thru 3448079 (When equipped
			with wheel D-30665);

* Denotes partial model eligibility
"MC" prefix denotes McFarlane Aviation, Inc. manufacture

Report Generated: 12/9/2020 12:17:34PM

