

P/N: 100R100000
CONTROL STICK GRIP
RIGHT HAND
BORE SIZE: 1 "
COLOR: BLACK

MOUNTING INSTRUCTIONS

1. SLIDE GRIP ONTO STICK AND CHECK FIT. IF TOO TIGHT, SAND O.D. OF CONTROL STICK.
2. USING T88 ADHESIVE OR A GOOD 2-PART EPOXY CEMENT, PLACE THE GRIP ON THE STICK AT THE DESIRED ANGLE (POINTING A FEW DEGREES TO THE LEFT) FOR MAXIMUM COMFORT.
3. WHEN THE ADHESIVE HAS SET (CURED), DRILL A #30 HOLE (.128") ON ONE SIDE OF THE CONTROL STICK, THROUGH THE GRIP WHERE A HOLE HAS BEEN PRE-DRILLED, AND INSTALL THE ENCLOSED POP-TYPE FLUSH RIVET.

MAKE SURE GRIP IS PROPERLY INSTALLED AND SECURE BEFORE FLYING!

PERSONAL MESSAGE:

WE THANK YOU FOR CHOOSING OUR AVIATION PARTS AND PRODUCTS FOR YOUR AIRCRAFT BUILDING PROJECT. WE ENDEAVOR TO FURNISH YOU THE HIGHEST QUALITY PARTS THAT TECHNOLOGY CAN AFFORD. YOU HAVE CHOSEN WELL. ALTHOUGH BUILDING AN AIRCRAFT CAN CONSUME MANY MONTHS AND YEARS, PERSISTENCE AND DETERMINATION WILL GUIDE YOU TO COMPLETION OF A SUCCESSFUL PROJECT. GOOD LUCK AND GOOD FLYING.

BUSINESS SYSTEMS and PRODUCTS
Manufacturers of the BSP aero grip
Menifee, California 92584
(951) 301-9802