



Propeller Aircraft Product Support

P.O. BOX 7708
WICHITA, KANSAS 67277

DATE: 11/11/2002
PAGE 1 OF 1
INCLUDING THIS COVER SHEET

TO: NAME: Tony Randall
 COMPANY: Wings Point Aviation
 FAX NUMBER: 972-548-2313

FROM: NAME: Duane Ayre
 DEPARTMENT: 753C
 TEL NUMBER: 318-517-5800
 FAX NUMBER: 318-942-9006

MESSAGES:

In response to your question regarding the installation of blind fasteners in the outboard section of the outboard seat rails on the Cessna model 177, 177B and 177RG aircraft. Cessna drawing number 1710000 shows installation of a number CR763 (as required) in the outboard section outboard seat rails of the above aircraft. The CR763 (designated as PO 4 on the drawing) fasteners are still available, however Cessna no longer carries them in stock since they are no longer manufactured in large quantities. Cessna Engineering prefers the use of blind fasteners that have a locking type stem, therefore its acceptable to use the CR3213 or the 1/84th oversize CR3243 series as a replacement for CR763 blind fastener. When ever possible Cessna Engineering wants all rivets that can be reached with a bucking bar to be solid driven rivets.